




ALLEN-BRADLEY

Bulletin 1335

Variable Torque AC Drive

(12 through 96 Amp)

Instruction Manual



Important User Information

Because of the variety of uses for this equipment and because of the differences between this solid state equipment and electromechanical equipment, the user of and those responsible for applying this equipment must satisfy themselves as to the acceptability of each application and use of the equipment. **In no event** will Allen-Bradley Company be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The illustrations shown in this manual are intended solely to illustrate the text of this manual. Because of the many variables and requirements associated with any particular installation, the Allen-Bradley Company **cannot** assume responsibility or liability for actual use based upon the illustrative uses and applications.

No patent liability is assumed by Allen-Bradley Company with respect to use of information, circuits or equipment described in this text.

Reproduction of the content of this manual, in whole or in part, without written permission of the Allen-Bradley Company is prohibited.



WARNINGS tell readers where people may be hurt if procedures are not followed properly.



CAUTIONS tell readers where machinery may be damaged or economic loss can occur if procedures are not followed properly.

Both of these Reader Alerts:

- Identify possible trouble spots.
- Tell what causes the trouble.
- Give the result of improper actions.
- Tell the reader how to avoid trouble.

Additionally:



SHOCK HAZARD labels may be located on or inside the Drive to alert people of hazards if service procedures are not followed properly.

**Repair or Repair/Exchange
Procedure**

For your convenience, the Allen-Bradley Motion Control Division, and the Allen-Bradley Support Division, provide an efficient and convenient method of returning equipment eligible for repair or repair/exchange.

A **Product Service Report (P.S.R.)** number is required to return any equipment for repair. This may be obtained from your local Allen-Bradley Area Sales/Support Center.

Return any equipment to be repaired to the Area Sales/Support Center nearest you. Be sure to reference the P.S.R. number on the carton and packing slip. Include your company name and address, your repair purchase order number, and a brief description of the problem. This will facilitate quick return of your equipment.

A complete listing of Area Sales/Support Centers is available from your local Allen-Bradley Distributor or Sales Office.

Manual Objective

This Instruction Manual defines the installation, startup, operation and troubleshooting procedures for the Allen-Bradley Bulletin 1335 12 through 96 Amp Variable Torque AC Drive and is intended for use by personnel familiar with the functions of solid state Drive equipment.

**CAUTION**

This assembly may contain ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed when testing, servicing or repairing this assembly. If you are not familiar with static control procedures, before servicing, reference U.S. Department of Defense, DOD-HDBK-263, Electrostatic Discharge Control Handbook for Protection of Electronic Parts, Assemblies and Equipment or any other applicable ESD Protection Handbook.

TABLE OF CONTENTS

| Section | Title | page |
|--|--|------|
| Chapter 1 Bulletin 1335 Pre-Installation Care | | |
| 1.0 | Pre-Installation & Operation | 1-1 |
| 1.1 | Receiving | 1-1 |
| 1.2 | Storage | 1-1 |
| 1.3 | Handling | 1-1 |
| 1.4 | Shipping | 1-1 |
| 1.5 | ESD Precautions | 1-2 |
| Chapter 2 Bulletin 1335 Drive Data | | |
| 2.0 | Catalog Number Explanation | 2-1 |
| Chapter 3 Bulletin 1335 460V Specifications | | |
| 3.0 | Specification Table | 3-1 |
| Chapter 4 Bulletin 1335 Installation Procedures | | |
| 4.0 | General Environmental Requirements | 4-1 |
| 4.1 | Nonventilated Sheet Metal Enclosures | 4-1 |
| 4.1.1 | Enclosure Sizing – Drive Chassis & Heatsink Inside the Enclosure | 4-2 |
| | table 4.1.1 – Watt & BTU Dissipation Data – Heatsink Inside the Enclosure | 4-2 |
| 4.1.2 | Enclosure Sizing – Drive Chassis Inside the Enclosure – Heatsink Outside the Enclosure ... | 4-2 |
| | table 4.1.2 – Watt & BTU Dissipation Data – Heatsink Outside the Enclosure | 4-2 |
| 4.2 | Dimensions and Weights | 4-3 |
| | 12 & 16 Amp Open Chassis (WITHOUT OPTION MOUNTING PANEL) | 4-3 |
| | 12 & 16 Amp Open Chassis (WITH OPTION MOUNTING PANEL) | 4-4 |
| | 22-96 Amp Open Chassis (WITHOUT OPTION MOUNTING PANEL) | 4-5 |
| | 22-96 Amp Open Chassis (WITH OPTION MOUNTING PANEL) | 4-6 |
| | 12 & 16 Amp NEMA Type 1 | 4-7 |
| | 22-96 Amp NEMA Type 1 | 4-8 |
| 4.3 | General Wiring Practices | 4-9 |
| 4.3.1 | Emergency STOP | 4-10 |
| 4.3.2 | Recommended Control Signal Wiring, Power Wiring & Conduit Entry Area | 4-10 |
| 4.3.3 | Chassis Ground, Power Input & Output Connections | 4-11 |
| | figure 4.3.3a – Bulletin 1335 12 & 16 Amp Power Input & Output Connections | 4-12 |
| | figure 4.3.3b – Bulletin 1335 22-96 Amp Power Input & Output Connections | 4-12 |
| 4.4 | Control Wiring | 4-13 |
| 4.4.1 | Terminal Block TB1 or 1TB Interconnection Notes | 4-13 |
| 4.4.2 | Terminal Block TB1 – 12 & 16 Amp Standard Interconnection Diagram | 4-14 |
| 4.4.3 | Terminal Block 1TB – 22-96 Amp Standard Interconnection Diagram | 4-15 |
| 4.4.4 | Interconnection Diagram – 12 & 16 Amp Field Installed RUN/STOP Control (120V AC) | 4-16 |
| 4.4.5 | Interconnection Diagram – 22-96 Amp Field Installed RUN/STOP Control (120V AC) | 4-16 |
| 4.4.6 | Interconnection Diagram – Field Installed RUN/STOP Control (90V AC) | 4-17 |
| 4.4.7 | Interconnection Diagram – Field Installed Remote Mounted Speed Pot | 4-17 |
| 4.4.8 | Interconnection Diagram – Field Installed Motor Thermostatic Switch | 4-18 |
| 4.4.9 | Interconnection Diagram – Field Installed Motor O.L. Relay & Thermostatic Switch | 4-18 |

| Section | Title | page |
|--|--|------|
| Chapter 5 Bulletin 1335 Startup & Adjustment Procedures | | |
| 5.0 | Prepower Check | 5-1 |
| 5.1 | Initial Operation | 5-1 |
| 5.2 | Bulletin 1335 Drive Data Log Sheets | 5-4 |
| 5.3 | Adjustment Procedures | 5-6 |
| 5.3.1 | Modulator Logic Board Potentiometer Settings | 5-6 |
| | figure 5.3.1 – Modulator Logic Board A1 | 5-7 |
| 5.3.2 | Modulator Logic Board Jumper Settings | 5-8 |
| 5.3.3 | Modulator Logic Board Switch Settings | 5-9 |
| | S1 ACCEL & S2 DECEL Rate Adjustments | 5-9 |
| | S3 DC Boost Adjustment | 5-11 |
| 5.3.4 | Driver Board Jumper Settings | 5-13 |
| | figure 5.3.4a – 12 & 16 Amp Driver Board | 5-14 |
| | figure 5.3.4b – 22 & 28 Amp Driver Board | 5-15 |
| Chapter 6 Bulletin 1335 Operation | | |
| 6.0 | Operating Considerations | 6-1 |
| | figure 6.0 – Square & Cube Law Load Curves | 6-1 |
| Chapter 7 Bulletin 1335 380/415 Volt Specifications & Adjustments | | |
| 7.0 | 380V Specification Table | 7-1 |
| 7.1 | 415V Specification Table | 7-2 |
| 7.2 | Adjustments | 7-3 |
| 7.2.1 | Transformer Adjustments | 7-3 |
| 7.2.2 | Volts-per-Hertz Adjustment | 7-4 |
| Appendix A Bulletin 1335 12 & 16 Amp Component Index | | |
| | 12 & 16 Amp Recommended Spare Parts | A-1 |
| | 12 & 16 Amp Component Access & Location | A-2 |
| | 12 & 16 Amp Component Location & Wiring | A-6 |
| | 12 & 16 Amp Component Wiring List | A-8 |
| Appendix B Bulletin 1335 22, 28 & 36 Amp Component Index | | |
| | 22, 28 & 36 Amp Recommended Spare Parts | B-1 |
| | 22 & 28 Amp Component Location | B-4 |
| | 36 Amp Component Location | B-6 |
| Appendix C Bulletin 1335 56 & 69 Amp Component Index | | |
| | 56 & 69 Amp Recommended Spare Parts | C-1 |
| | 56 & 69 Amp Component Location | C-3 |
| Appendix D Bulletin 1335 77 & 96 Amp Component Index | | |
| | 77 & 96 Amp Recommended Spare Parts | D-1 |
| | 77 & 96 Amp Component Location | D-3 |

| Section | Title | page |
|--|-------|------|
| Appendix E Bulletin 1335 12 & 16 Amp Troubleshooting | | |
| 12 & 16 Amp Diagnostic LED Display | | E-1 |
| 12 & 16 Amp Troubleshooting Procedures | | E-2 |
| Appendix F Bulletin 1335 22, 28 & 36 Amp Troubleshooting | | |
| 22, 28 & 36 Amp Diagnostic LED Display | | F-1 |
| 22, 28 & 36 Amp Troubleshooting Procedures | | F-2 |
| Appendix G Bulletin 1335 56 & 69 Amp Troubleshooting | | |
| 56 & 69 Amp Diagnostic LED Display | | G-1 |
| 56 & 69 Amp Driver Board LED Indication | | G-2 |
| 56 & 69 Amp Troubleshooting Procedures | | G-3 |
| Appendix H Bulletin 1335 77 & 96 Amp Troubleshooting | | |
| 77 & 96 Amp Diagnostic LED Display | | H-1 |
| 77 & 96 Amp Driver Board LED Indication | | H-2 |
| 77 & 96 Amp Troubleshooting Procedures | | H-3 |
| Appendix I Bulletin 1335 12 & 16 Amp Drive Schematics | | |
| 12 & 16 Amp Unit Schematic | | I-1 |
| 12 & 16 Amp Power Distribution Board Schematic | | I-2 |
| Appendix J Bulletin 1335 22, 28 & 36 Amp Unit Schematics | | |
| 22 & 28 Amp Unit Schematic | | J-1 |
| 36 Amp Unit Schematic | | J-2 |
| Appendix K Bulletin 1335 56 & 69 Amp Unit Schematic | | |
| 56 & 69 Amp Unit Schematic | | K-1 |
| Appendix L Bulletin 1335 77 & 96 Amp Unit Schematic | | |
| 77 & 96 Amp Unit Schematic | | L-1 |
| Appendix M Bulletin 1335 Modulator Logic Board Interconnection Diagrams | | |
| 12 & 16 Amp Modulator Logic Board Interconnection Diagram | | M-1 |
| 22-96 Amp Modulator Logic Board Interconnection Diagram | | M-2 |
| Bulletin 1335 Modulator Logic Board Plug-In Options | | M-3 |
| CARD EDGE CONNECTOR J107 | | M-3 |
| CARD EDGE CONNECTOR J102 | | M-4 |
| CARD EDGE CONNECTOR J104 | | M-5 |
| CARD EDGE CONNECTOR J105 | | M-6 |
| CARD EDGE CONNECTOR J103 | | M-7 |

Bulletin 1335 Pre-Installation Care

**1.0
Pre-Installation & Operation**

Before installing and operating your Bulletin 1335, carefully read this manual and observe all precautions. The catalog number of your Drive as explained in **Chapter 2** lists the Drive rating, type of enclosure, nominal line voltage, phase and frequency, as well as any additional options that were specified. Specifications for all Bulletin 1335 Drives including standard controls, adjustment range, diagnostics, and environmental qualifications are listed in **Chapter 3**. 380 & 415V Bulletin 1335 specifications and adjustments are detailed in **Chapter 7**.

**1.1
Receiving**

Once you have received your Bulletin 1335 Drive, careful inspection for shipping damage should be made. Damage to the shipping carton is usually a good indication that it has received rough handling. Any and all damage should be immediately reported to the freight carrier and your nearest Allen-Bradley Area Sales/Support Center.

Carefully unpack the Drive taking care to save the shipping carton and any packing material should return be necessary. Verify that the items on the packing list or bill of lading agree with your order.

**1.2
Storage**

If the Drive will not immediately be installed, it should be stored in a clean, dry area where the ambient temperature is not less than -25°C nor more than $+65^{\circ}\text{C}$. The Drive should not be stored in a corrosive environment or subject to conditions in excess of the storage environment parameters stated in the **Specification Table**, Chapter 3.

**1.3
Handling**

Depending upon the rating and options ordered, in its shipping carton your Bulletin 1335 can weigh anywhere from 94 to over 500 lbs. Proper safety precautions and practices should be observed whenever the Drive is being moved from one location to another.

**1.4
Shipping**

The carton and materials that came with your Drive have been designed and tested to provide reasonable protection against damage during transit. Should shipment of the Drive to another location be required, it is recommended that the original shipping carton and packing material be used to protect the Drive from damage during transit.

1.5
ESD Precautions



CAUTION

This assembly may contain ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed when testing, servicing or repairing this assembly. If you are not familiar with static control procedures, before servicing, reference U.S. Department of Defense, DOD-HDBK-263, Electrostatic Discharge Control Handbook for Protection of Electronic Parts, Assemblies and Equipment or any other applicable ESD Protection Handbook.


ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage when circuit boards are removed or installed, it is recommended that the following minimum precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
- *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
- *When removing any circuit board from the Drive, immediately place it in conductive packing material.*

Bulletin 1335 Drive Data

2.0
Catalog Number Explanation

The following is an explanation of the catalog numbering system for Bulletin 1335 Variable Torque AC Drives. The catalog number for your Drive can be found both on the packing carton and the Drive nameplate.



For Multiple Options, code letters are strung together as necessary separated by a dash.

IMPORTANT

For 380 or 415V AC operation a Function Expander Card (Option L) or Euro Card is required to provide proper volts-per-hertz for 50 Hz motors (the Euro Card is provided as standard for all 380 or 415V AC, 50 Hz Drives).

Bulletin 1335 460V Specifications

3.0 Specification Table

The following table lists all specifications for Bulletin 1335 Variable Torque AC Drives. All Bulletin 1335 Drives are U.L. listed. All Bulletin 1335 Drives are 460V, sine-weighted, PWM type voltage source inverters that have the capability of operating at 415V AC or 380V AC — 380 & 415V Bulletin 1335 specifications and adjustments are detailed in Chapter 7. Unless otherwise specified, all descriptions of operation and performance throughout this manual will reference the 460V AC, 60 Hz unit.

IMPORTANT

The Bulletin 1335 produces a sine-weighted, PWM output voltage at a variable output frequency for application to a standard 3 phase, NEMA Design B induction motor. For applications other than standard NEMA Design B motors, consult your nearest Allen-Bradley Area Sales/Support Center.

| Model and Ratings 12 & 16 Amp | Model Number | 1335-D _ B | 1335-E _ B |
|--|------------------|------------|------------|
| | Output Amps | 12.0 | 16.0 |
| | Output Voltage | 0-460 | 0-460 |
| | Output kVA | 9.6 | 12.7 |
| | Input Amps | 10.5 | 14.0 |
| | Input Voltage | 460 | 460 |
| | Input kVA | 8.4 | 11.2 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 60 | 60 |

| Model and Ratings 22, 28 & 36 Amp | Model Number | 1335-F _ B | 1335-G _ B | 1335-R _ B |
|--|------------------|------------|------------|------------|
| | Output Amps | 22.0 | 28.0 | 36.0 |
| | Output Voltage | 0-460 | 0-460 | 0-460 |
| | Output kVA | 17.5 | 22.3 | 28.7 |
| | Input Amps | 19.3 | 25.3 | 33.6 |
| | Input Voltage | 460 | 460 | 460 |
| | Input kVA | 15.4 | 20.2 | 26.8 |
| | Output Frequency | 0-200 | 0-200 | 0-200 |
| | Input Frequency | 60 | 60 | 60 |

3.0
Specification Table
(continued)

| Model and Ratings 56 & 69 Amp | Model Number | 1335-J _ B | 1335-K _ B |
|--|------------------|------------|------------|
| | Output Amps | 56.0 | 69.0 |
| | Output Voltage | 0-460 | 0-460 |
| | Output kVA | 44.6 | 55.0 |
| | Input Amps | 52.4 | 63.5 |
| | Input Voltage | 460 | 460 |
| | Input kVA | 41.7 | 50.6 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 60 | 60 |

| Model and Ratings 77 & 96 Amp | Model Number | 1335-L _ B | 1335-N _ B |
|--|------------------|------------|------------|
| | Output Amps | 77.0 | 96.0 |
| | Output Voltage | 0-460 | 0-460 |
| | Output kVA | 61.3 | 76.5 |
| | Input Amps | 70.8 | 88.2 |
| | Input Voltage | 460 | 460 |
| | Input kVA | 56.4 | 70.3 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 60 | 60 |

| Power Supply | Allowable Variation | Input Voltage — 460V, 3Ø, ±10% |
|---------------------------|-----------------------------------|---|
| | | Input Frequency — 60 Hz, ±2% |
| Control Specifications | Output Waveform Control Scheme | Sine Weighted PWM Control |
| | Output Switching Device | Transistor Power Switching Module |
| | Output Frequency Regulation | ±0.6Hz at 0-40°C Ambient (Analog Input Mode) |
| | Voltage – Operator Controls | Standard 90V AC Drive Supply (Customer 120V AC External Supply Allowed) |
| | Overload Capability | 110% (Nominal) of Rated Drive Output Current for 60 Seconds |

3.0
Specification Table
(continued)

| | | |
|-----------------------------------|-------------------------------------|---|
| Standard Controls and Adjustments | ① Volts-per-Hertz Selection | 3.8V/Hz or 7.6V/Hz (Standard) |
| | DC Boost | 0-34 Volts |
| | Minimum Speed Pot Setting | 0-40Hz |
| | Maximum Speed Pot Setting | 40-200Hz |
| | ② ACCEL/DECEL Rate Adjustment | ACCEL/DECEL Time of 0.4-50 Sec at 0-60Hz Independently Selectable Rates From 1.2 to 152.4 Hz/Sec |
| Protection Circuits and Devices | Stop Mode | Coast-to-Stop |
| | Input Protection | Fused for 200,000 Amps Symmetrical Interrupting Capacity |
| | Power Loss Ride-Thru | Nominal .05 Seconds |
| | Input Transient Protection | Up to 5,000 Volts Peak at 150Ω Line Impedance |
| | Overload | Allows Drive to "Ride-Thru" Nominal 110% Overloads for up to 1 Minute by Limiting Output Current |
| | ① Input Under Voltage | 414 Volts Nominal |
| | Output Phase-to-Phase Short Circuit | Monitors Excessive Current in Each Transistor (180% Nominal of Rated Drive Output Current) |
| | Drive Over Temperature | N.C. Thermal Switch on Heatsink |
| | Output Ground Short Circuit | Protects Drive Against Output Phase-to-Ground Faults |
| | Power ON Light | LED Indication When AC Line Power Is Applied to the Drive |
| Diagnostics | Momentary Overload Protection | LED Indication When a Momentary Drive Overload Occurs or a Momentary Drive Overload has Caused the Drive to Shut Down |
| | Input Under Voltage | LED Indication if Input Line Drops Below 10% of Rated Drive Input Voltage |
| | Bus Over Voltage | LED Indication if Bus Rises Above 760V DC |
| | A, B or C Phase Protect | Individual LED Indication if Drive Transistor Current in Any Phase Exceeds 180% (Nominal) of Rated Drive Output Current |
| | Drive Over Temperature | LED Indication if the Heat Sink Temperature of the Drive Reaches the Maximum Guideline Temperature of the Components |
| | Bus Charged | Neon Light Indication When Bus Voltage Is Greater Than 42V DC |
| | Output Ground | LED Indication if the Drive Output Circuitry Has Shorted to Ground (22 through 96 Amp Units Only) |

IMPORTANT: ① For 380 or 415V AC operation, refer to Chapter 7.

② When an analog speed command is applied to the Drive, total ACCEL/DECEL time will be 0.5 to 1.6 seconds longer due to an RC type exponential tapering into the new speed. Rates specified are accurate when a speed command from a BCD Interface Card (option G4) is used.

3.0
Specification Table
(continued)

| | | | |
|------------------------------|--|---|---|
| Operating Environment | Ambient Operating Temperature | All Ratings Open : 0-40°C Without Derating Enclosed : 0-40°C Without Derating | |
| | Relative Humidity | 5 to 95% Noncondensing | |
| | Vibration (Normal Mounting Position) | .006 Displacement, 1G Peak | |
| | Shock (Normal Mounting Position) | 15G Peak for 11mS Duration (± 1.0mS) | |
| | Elevation | All Ratings – 3,300 ft. Without Derating | |
| | Noise Immunity | Showering Arc Transients from 350 to 2,000 Volts | |
| Storage Environment | Ambient Storage Temperature | -25°C to 65°C Enclosed and Open Chassis | |
| | Relative Humidity | 5 to 95% Noncondensing | |
| Enclosure | Open Chassis | Available for All Ratings | |
| | NEMA Type 1 | Available for All Ratings | |
| Efficiency | Minimum Efficiency & Input Power Factor at 60 Hz, Full-Load | UNIT | DRIVE EFFICIENCY ① DRIVE POWER FACTOR |
| | | 12 Amp | 94% .90 kW/kVA |
| | | 16 Amp | 95% .92 kW/kVA |
| | | 22 Amp | 96% .91 kW/kVA |
| | | 28 Amp | 96% .92 kW/kVA |
| | | 36 Amp | 95% .91 kW/kVA |
| | | 56 Amp | 96% .92 kW/kVA |
| | | 69 Amp | 96% .92 kW/kVA |
| | | 77 Amp | 94% .93 kW/kVA |
| | | 96 Amp | 94% .94 kW/kVA |

① Drive displacement angle power factor is 0.95 to 0.97 constant. Listed values are displacement plus distortion power factor (kW/kVA).

Bulletin 1335 Installation Procedures

**4.0
General
Environmental Requirements**

The Bulletin 1335 should be installed in an area where the following installation and environmental guidelines can be met.

- *Cabinet mounting is upright, leaving room for door clearance and a minimum clearance of (6) inches on all sides for proper ventilation.*
- *The Drive is easily accessible for maintenance and troubleshooting.*
- *The rated altitude does not exceed 3,300 ft. (1,006 meters).*
- *Vibration will be kept to a minimum as outlined in the Specification Table, Chapter 3.*
- *The ambient atmosphere is free of corrosive gases.*
- *The relative humidity is kept to within 95% for all Drive ratings.*

For NEMA Type 1 Drives

- *The rated ambient temperature should not exceed 40°C.*

For Open Chassis Drives

- *The rated heatsink ambient temperature should not exceed 40°C.*
- *The rated chassis component ambient temperature should not exceed 50°C.*

If the ambient temperature and/or altitude of the Drive installation site exceeds these values, contact your nearest Allen-Bradley Area Sales/Support Center for derating information.

**4.1
Nonventilated
Sheet Metal Enclosures**

There are two ways in which an open chassis Drive can be installed in a NEMA Type 1 or 12 enclosure.

1. With both the Drive chassis and heatsink inside the enclosure.
2. With the Drive chassis inside the enclosure and the heatsink extended out the back of the enclosure — *A NEMA Type 12 rating may not be maintained if this method is used for Drives with an option mounting panel.*

In either case, each Drive chassis must have a customer supplied fan installed that will supply at least 100CFM to circulate air up through the Drive chassis. For 56 through 96 Amp Drives which already have an integrally mounted fan, an additional 100 CFM fan must be mounted directly above the chassis to draw air up through the Drive chassis.

- Allow a minimum clearance of at least (6) inches between each Drive chassis when mounting them in a common enclosure.
- Determine the total watt dissipation of all Drives and other heat generating components to be mounted inside the enclosure such as transformers, etc. Total watt dissipation for Bulletin 1335 Drives with both the Drive chassis and heatsink inside the enclosure is shown in table 4.1.1.

Do not include the bottom surface area of the enclosure.

Do not include the back surface area of the enclosure if the enclosure is closer than (6) inches to a wall or other surface.

Do not use more than one-half of the top surface area. Dust and debris accumulating on the top surface over time reduces the ability of the top surface to dissipate heat.

**4.1.1
Enclosure Sizing
– Drive Chassis and
Heatsink Inside the Enclosure**

Although the Drive chassis (excluding the heatsink) is rated for a maximum ambient air temperature of 50°C, the Drive heatsink itself is rated for a maximum ambient air temperature of 40°C. When mounting an open chassis type Drive with the heatsink inside the enclosure, use **table 4.1.1** in combination with the enclosure manufacturer's guidelines for sizing the enclosure. Follow the guidelines listed in **section 4.1** to help ensure that the temperature within the enclosure does not exceed 40°C.

| FULL LOAD OUTPUT AMPS | VOLTS | WATTS DISSIPATED | BTUs/HR DISSIPATED |
|--------------------------|-------|---------------------|-----------------------|
| 12 | 460 | 440 | 1,502 |
| 16 | 460 | 490 | 1,673 |
| 22 | 460 | 560 | 1,911 |
| 28 | 460 | 740 | 2,526 |
| 36 | 460 | 1,205 | 4,113 |
| 56 | 460 | 1,520 | 5,188 |
| 69 | 460 | 1,850 | 6,315 |
| 77 | 460 | 3,150 | 10,752 |
| 96 | 460 | 4,010 | 13,687 |

**table 4.1.1 – Watt & BTU Dissipation Data for Open Chassis Drives
with Heatsink Inside the Enclosure**

**4.1.2
Enclosure Sizing
– Drive Chassis
Inside the Enclosure
– Heatsink Outside the Enclosure**

Even when the Drive is mounted with the heatsink outside the enclosure, there is still heat dissipated within the enclosure by the Drive chassis. **Table 4.1.2** lists the heat dissipation of only the Drive chassis with the Drive heatsink mounted outside the enclosure in a 40°C ambient. Use **table 4.1.2** in combination with the enclosure manufacturer's guidelines for sizing the enclosure. Follow the guidelines listed in **section 4.1** to help ensure that the temperature within the enclosure does not exceed 50°C when the Drive chassis is mounted inside the enclosure while the Drive heatsink is mounted outside the enclosure.


| FULL LOAD OUTPUT AMPS | VOLTS | WATTS DISSIPATED | BTUs/HR DISSIPATED |
|--------------------------|-------|---------------------|-----------------------|
| 12 | 460 | 140 | 478 |
| 16 | 460 | 150 | 512 |
| 22 | 460 | 160 | 546 |
| 28 | 460 | 240 | 819 |
| 36 | 460 | 355 | 1,212 |
| 56 | 460 | 470 | 1,605 |
| 69 | 460 | 550 | 1,878 |
| 77 | 460 | 1,650 | 5,634 |
| 96 | 460 | 2,160 | 7,375 |

**table 4.1.2 – Watt & BTU Dissipation Data for Open Chassis Drives
with Heatsink Outside the Enclosure**

DOB & EOB MOUNTING BOLTS
R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)

4.2 Dimensions & Weights (continued)


ROB MOUNTING BOLTS
R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)



22-96 Amp Open Chassis (WITHOUT OPTION MOUNTING PANEL)

FOB & GOB MOUNTING BOLTS
R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)


JOB, KOB, LOB & NOB MOUNTING BOLTS
R1 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)




| MODEL | DIMENSIONS IN INCHES AND (MILLIMETERS) | | | | | | | WEIGHTS IN POUNDS AND (KILOGRAMS) | |
|-------|---|------------------|------------------|--------------------|------------------|----------------|----------------|---|------------------|
| | | | | | | | | WITHOUT OPTION MOUNTING PANEL OR OPTIONS | |
| | A | B | C | D | E | F | G | SHIPPING | MOUNTING |
| FOB | 38.00 (965.2) | 17.50 (444.5) | 13.06 (331.7) | 37.00 (939.8) | 16.00 (406.4) | 0.50 (12.7) | 0.75 (19.1) | 165.00 (74.8) | 143.00 (64.9) |
| GOB | | | | | | | | 168.00 (76.2) | 146.00 (66.2) |
| ROB | 38.00 (965.2) | 17.50 (444.5) | 13.56 (344.4) | 37.00 (939.8) | 16.00 (406.4) | 0.50 (12.7) | 0.75 (19.1) | 199.00 (90.2) | 177.00 (80.3) |
| JOB | 50.00 (1,270.0) | 17.50 (444.5) | 13.88 (352.6) | 49.00 (1,244.6) | 16.00 (406.4) | 0.50 (12.7) | 0.75 (19.1) | 333.00 (151.0) | 208.00 (94.3) |
| KOB | | | | | | | | 335.00 (151.9) | 210.00 (95.2) |
| LOB | | | | | | | | 340.00 (154.2) | 215.00 (97.5) |
| NOB | | | | | | | | 345.00 (156.5) | 220.00 (99.8) |

4.2
 Dimensions & Weights
 (continued)

22-96 Amp Open Chassis
 (WITH OPTION MOUNTING PANEL)




4.2 Dimensions & Weights (continued)



12 & 16 Amp NEMA Type 1

DAB & EAB MOUNTING BOLTS
R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)
R2 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)

[illegible]

4.2
 Dimensions & Weights
 (continued)

22-96 Amp NEMA Type 1

FAB & GAB MOUNTING BOLTS


R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)
 R2 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)

RAB MOUNTING BOLTS

R1 = 0.31" DIA. — MAX. BOLT HEAD = 0.62" — 1/4" SCREW (TYP.)
 R2 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)

JAB, KAB, LAB & NAB MOUNTING BOLTS

R1 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)
 R2 = 0.44" DIA. — MAX. BOLT HEAD = 1.00" — 3/8" SCREW (TYP.)



| MODEL | DIMENSIONS IN INCHES AND (MILLIMETERS) | | | | | | | | | WEIGHTS IN POUNDS AND (KILOGRAMS) | | | |
|-------|---|-------------------|------------------|--------------------|------------------|------------------|----------------|----------------|----------------|--------------------------------------|-------------------|-------------------|-------------------|
| | | | | | | | | | | WITHOUT OPTIONS | | WITH OPTIONS | |
| | A | B | C | D | E1 | E2 | F | G1 | G2 | SHIPPING | MOUNTING | SHIPPING | MOUNTING |
| FAB | 38.00 (965.2) | 29.00 (736.6) | 15.12 (384.0) | 37.00 (939.8) | 16.00 (406.4) | 26.12 (663.4) | 0.50 (12.7) | 0.75 (19.1) | 2.12 (53.8) | 237.00 (107.5) | 215.00 (97.5) | 247.00 (112.0) | 225.00 (102.1) |
| GAB | | | | | | | | | | 242.00 (109.8) | 220.00 (99.8) | 262.00 (118.8) | 240.00 (108.9) |
| RAB | 38.00 (965.2) | 29.00 (736.6) | 15.62 (396.7) | 37.00 (939.8) | 16.00 (406.4) | 26.12 (663.4) | 0.50 (12.7) | 0.75 (19.1) | 2.12 (53.8) | 272.00 (123.4) | 250.00 (113.4) | 302.00 (137.0) | 275.00 (124.7) |
| JAB | 50.00 (1,270.0) | 32.50 (825.50) | 15.62 (396.7) | 49.00 (1,244.6) | 16.00 (406.4) | 29.38 (746.3) | 0.50 (12.7) | 0.75 (19.1) | 2.38 (60.5) | 500.00 (226.8) | 375.00 (170.1) | 525.00 (238.1) | 400.00 (181.4) |
| KAB | | | | | | | | | | 512.00 (232.2) | 387.00 (175.5) | 542.00 (245.8) | 417.00 (189.2) |
| LAB | | | | | | | | | | 517.00 (234.5) | 392.00 (177.8) | 548.00 (248.6) | 423.00 (191.9) |
| NAB | | | | | | | | | | 522.00 (236.8) | 397.00 (180.1) | 553.00 (250.8) | 428.00 (194.1) |

4.3 General Wiring Practices

Depending on the Drive model number ordered, the Bulletin 1335 Adjustable Frequency Drive is designed to operate from either:

- A 3Ø, 60 Hz, 460V AC Input Source
- A 3Ø, 50 Hz, 380V AC Input Source
- A 3Ø, 50 Hz, 415V AC Input Source

Unless otherwise specified, the following information references the 460V AC, 60Hz unit. Refer to **Chapter 7** for 380 & 415V information.

The Drive maximum output voltage is approximately equal to the applied input voltage. Since the Drive maximum continuous current rating does not change with input voltage, the Drive output kVA rating decreases directly with input voltage.

For input AC supply voltages other than those listed in the specifications, an input transformer must be used and connected as indicated on the transformer.

The National Electrical Code (NEC) and local regulations govern the installation and wiring of the Bulletin 1335 Drive. Input power wiring, output power wiring, control wiring, and conduit should be sized and installed in accordance with these codes, the Drive nameplate data, and any Allen-Bradley information supplied with your Drive.

IMPORTANT

- 1) The National Electrical Code (NEC) requires that branch circuit protection of the AC line input power to the Drive be provided by circuit breaker or fusible disconnect switch. The standard Bulletin 1335 Drive does not provide this requirement.
- 2) The National Electrical Code requires that motor overload protection be provided in the motor branch circuit. The standard Bulletin 1335 Drive does not provide this requirement.

Eutectic Alloy or bi-metal overload relays can be utilized to provide running overcurrent protection. Due to the reduced cooling capacity of motors running at low speed (full load), overload relays typically can not provide accurate protection against overheating below 50% of base speed.

Inverse time protection against motor overload can be obtained by means of the Bulletin 1335 Motor Overload Relay, Option T14 through T22.

Refer to article 430 of the NEC and any additional local codes for specific requirements and additional information.

4.3.1
Emergency STOP



CAUTION

The START/STOP control circuitry in the Bulletin 1335 Drive includes solid state components. If hazards due to accidental contact with moving machinery or unintentional flow of liquid, gas or solids exist, an additional hard wired emergency stop circuit may be required. Refer to codes and standards applicable to your particular system for specific requirements and additional information. A device that removes AC input power when an emergency stop is initiated can be used. When AC input power is removed however, there will be a loss of inherent regenerative braking effect and the motor will coast to a stop. An auxiliary braking method may be required.

After an emergency stop has been initiated, allow at least (5) seconds to elapse before reapplying AC input power to the Drive. The allowable number of emergency start/stops are (5) cycles of (3) starts per minute at (20) second intervals. Wait (5) minutes before attempting the next (5) cycles.


4.3.2
Recommended
Control Signal Wiring,
Power Wiring &
Conduit Entry Area



CAUTION

When drilling into the Drive enclosure, be sure to protect Drive components from metal chips that could cause damage to the Drive once power is applied.

All power wiring, control wiring and conduit to the Bulletin 1335 must be made through the access panel at the top of the Drive enclosure. Prior to drilling through the access panel, it is recommended that the panel be removed to protect the Drive components from falling metal chips.



(top view)

Connections to the Drive should be made as described in the following sections and in accordance with any additional interconnection diagrams packed with the Drive. Verify that shielded cable and/or steel conduit is used if indicated on any interconnection diagram.

4.3.3 Chassis Ground, Power Input & Output Connections

The input and output power connections to the Drive discussed in this section are for the standard Bulletin 1335 Drive. The standard Bulletin 1335 Drive does not include any of the available options. Additional Drive option information and connection drawings are supplied with the Drive as supplements to this manual.



WARNING

Bulletin 1335 Drives have two ground lugs labeled **GND** provided at the top of the Drive back panel. To guard against equipment damage or injury to personnel, one of these lugs must be connected to earth ground as shown. Additionally, the motor frame must also be connected to earth ground.



CAUTION

Power factor correction capacitors connected to the Drive output cannot be used. The switching of power factor correction capacitors on the input AC line of the Drive may cause damage to the Drive.

If your application requires the use of power factor correction capacitors or output contactors, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.

IMPORTANT

The Bulletin 1335 produces a sine-weighted, PWM output voltage at a variable output frequency for application to a standard 3 phase, NEMA Design B induction motor. For applications other than standard NEMA Design B motors, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.




figure 4.3.3a – Bulletin 1335 12 & 16 Amp Power Input & Output Connections




figure 4.3.3b – Bulletin 1335 22-96 Amp Power Input & Output Connections

- 4.4 Control Wiring** The information on the following pages references control wiring, either factory supplied or field installed. All control wiring should be connected as shown in the following interconnection diagrams. The control and interconnection wiring to the Drive discussed in this section are for the standard Bulletin 1335 Drive. The standard Bulletin 1335 Drive does not include any of the available options. Additional Drive option information and connection drawings are supplied with the Drive as supplements to this manual.
- 4.4.1 Terminal Block TB1 or 1TB Interconnection Notes** Terminal Blocks TB1 (12 & 16 Amp Drives) and 1TB (22-96 Amp Drives) have identical control wiring interconnections except as noted in **sections 4.4.2 – 4.4.5.**



CAUTION

Motor Thermostatic Switch

Direct connection of a motor thermostatic switch to the Drive control circuit may damage the Drive. If a motor thermostatic switch is required to be connected to the Drive control circuit:

Use an interposing N.O. relay contact (customer furnished) to isolate the thermostatic switch from the Drive control circuit. Connect the relay contact between terminals 10 & 11 at Terminal Block TB1 or 1TB as shown in section 4.4.8.

If the Drive is equipped with a Motor Overload Relay, the interposing relay contact from the motor thermostatic switch should be wired in series with the normally closed contact of the Motor Overload Relay as shown in section 4.4.9.

Control Signal Wiring

- 1) **All Control Signal Wiring** must be run separate from power wiring in its own separate ferrous metal conduit.
- 2) If **Control Signal Wiring is Required**, any nearby relays, solenoids, or brake coils can produce electrical noise transients and cause erratic Drive behavior. An R-C suppressor device should be added across the coils of these devices. As an alternate, a 220Ω resistor in series with a 0.5μF, 600V capacitor can be used as a suppressor in 120V AC circuits.

Remote Mounted Speed Pot

- 1) Wiring must be twisted, three conductor wire, having (2) to (3) twists per inch.
- 2) Wiring must be run in separate ferrous metal conduit to minimize the possibility of electrical noise.
- 3) If **Shielded Wire is Required**, the shield must be connected to ground only at Terminal Block TB1 or 1TB, term. 11 – The other end must be left floating.

Field Installed START/STOP Control

- 1) If **Remotely Mounted**, wiring must be run in conduit separate from any speed reference or power wiring.
- 2) When Using **Remote (3) Wire STOP/START Pushbutton Control**, the local STOP pushbutton must be wired in series with the remote STOP pushbutton. Disconnect existing wires from terminals 8 & 9 and remove the START pushbutton. Install a closing plug and remove or cover the START legend. Refer to **sections 4.4.2 & 4.4.3.**
- 3) When Using **(2) Wire START/STOP Control Via a Relay Contact**, disconnect existing wires from terminals 7, 8 & 9 and remove both the START & STOP pushbuttons. Install closing plugs and remove or cover both the START and STOP legends. Refer to **sections 4.4.4, 4.4.5 & 4.4.6.**



WARNING

When using (2) wire START/STOP control via a maintained START or RUN contact, the Drive will automatically restart after loss of AC input power once power is restored. Personal injury may occur if labels are not located at the Drive and associated machinery to warn operators/service personnel of the potential hazard. Warnings should include procedures to lock-out power at the disconnect device when servicing equipment.

4.4.2 Terminal Block TB1 12 & 16 Amp Standard Interconnection Diagram


IMPORTANT

TERMINAL BLOCK TB1 INTERCONNECTIONS

The maximum wire size TB1 will accept is 18 AWG – Stranded wire recommended.

Terminal Block TB1 has captive termination screws.

- Do Not Back Screws Completely Out
- Do Not Lug Terminations



① Components May be Supplied by User or Allen-Bradley

② When Using Remote (3) Wire STOP/START Control, the Local STOP Pushbutton Must Be Wired in Series with the Remote STOP Pushbutton


- Disconnect Existing START Pushbutton Wires From Terminals 8 & 9 and Remove the START Pushbutton
- Install a Closing Plug and Remove or Cover the START Legend

③ Remove Jumper When Connecting Option

⏏ Drive Common


⏏ Chassis Ground

4.4.3 Terminal Block 1TB 22-96 Amp Standard Interconnection Diagram




- ① Components May be Supplied by User or Allen-Bradley
- ② When Using Remote (3) Wire STOP/START Control, the Local STOP Pushbutton Must Be Wired in Series with the Remote STOP Pushbutton
 - Disconnect Existing START Pushbutton Wires From Terminals 8 & 9 and Remove the START Pushbutton
 - Install a Closing Plug and Remove or Cover the START Legend
- ③ Remove Jumper When Connecting Option
- ⚡ Drive Common
- ⏏ Chassis Ground

4.4.4
Interconnection Diagram
– 12 & 16 Amp
Field Installed Run/Stop Control
(2-Wire 120V AC, External Supplied)




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
- Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
 - Install Closing Plugs and Remove or Cover Both the START & STOP Legends
- ↘ Drive Common
⏏ Chassis Ground
⏏ Earth Ground

4.4.5
Interconnection Diagram
– 22-96 Amp
Field Installed Run/Stop Control
(2-Wire 120V AC, External Supplied)




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
- Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
 - Install Closing Plugs and Remove or Cover Both the START & STOP Legends
- ↘ Drive Common
⏏ Chassis Ground
⏏ Earth Ground

4.4.6
Interconnection Diagram
– Field Installed
Run/Stop Control
(2-Wire 90V AC, Drive Supplied)




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
- Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
 - Install Closing Plugs and Remove or Cover Both the START & STOP Legends


4.4.7
Interconnection Diagram
– Field Installed
Remote Mounted Speed Pot



4.4.8
Interconnection Diagram
– Field Installed
Motor Thermostatic Switch



4.4.9
Interconnection Diagram
– Field Installed
Motor Overload Relay & Thermostatic Switch



Bulletin 1335 Startup & Adjustment Procedures

**5.0
Prepower Check**

Each Drive is functionally tested at the factory. It has been adjusted for the output voltage and frequency range indicated on the Drive nameplate. If new settings must be made to meet additional equipment requirements or operator preferences, refer to **section 5.3, Adjustment Procedures**.

Prior to operating the Drive, become familiar with the Drive by locating and identifying all major components for your Drive in **Appendix A, B, C or D**. Refer to the **Diagnostic Display Panel** for your Drive in **Appendix E, F, G or H** to become familiar with the fault indication features. Once the Drive has been installed and wired as outlined in **section 4.3, General Wiring Practices**, and **section 4.4, Control Wiring**, proceed as follows.

**WARNING**

Use specified incoming line fuses to guard against equipment damage and hazards due to failure of electrolytic capacitors.

Hazardous voltage levels exist on some printed circuit boards and the Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the **STOP** pushbutton has been depressed.

For 12 & 16 Amp Drives if neon light **DS1** on Power Distribution Board A2 is lit, hazardous voltages are present in the Drive cabinet.

For 22-96 Amp Drives if neon light **DS1** on Bus Indicator Board A41 is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected or fuses are being replaced always:

Remove Power to the Drive at the Disconnect Device and wait (60) Seconds To Ensure That DS1 Is Not Lit Before Servicing

**5.1
Initial Operation**

Before applying input power to the Drive for the first time:

- Verify that all wiring to the Drive is correct and in compliance with the **Installation Procedures** as stated in **Chapter 4** and any additional or supplemental information provided with the Drive.
- With an ohmmeter set to its highest scale, check for grounds between the Drive output terminals and chassis ground (**GND**), as well as between the Drive input terminals and chassis ground (**GND**). Should any unintentional grounds be found, determine their cause and eliminate them prior to applying input power to the Drive.

5.1
Initial Operation
(continued)

The Bulletin 1335 employs "power loss ride-thru" which prevents the Drive from shutting down on intermittent loss of input voltage for a nominal 50mS (3 cycles or less). Due to this, the output Power Switching Modules will be turned off after approximately 50mS in response to either a STOP command or the removal of input AC line power to the Drive.



CAUTION : To Guard Against Equipment Damage, Before Pressing the START Pushbutton, Ensure:

That the Speed Pot or speed reference is set to **MINIMUM** (fully CCW).

That any **AUTO/OFF/MAN** or **AUTO/MAN** switches are set to **MAN**.

That the **DRIVE/OFF/BYPASS** switch if installed is set to **DRIVE**.

That the motor is uncoupled from its mechanical load.

IMPORTANT

Drive Fault Trips

Before resetting any fault trip refer to the Bulletin 1335 Troubleshooting Appendix for your Drive — **E, F, G or H** — to isolate and correct the fault.

**Determine the Correct Direction
of Motor Rotation**

Step 1 With power removed to the Drive at the disconnect device, set operator switches.

- If the Drive is equipped with an **AUTO/OFF/MAN** switch, set the switch to **MAN**.
- If the BCD Interface or Isolated Signal Conditioner Card is installed, ensure that the card mounted **AUTO/MAN** switch is set to **MAN**.

Step 2 Apply power to the Drive at the disconnect device.

Contactor **K1** or **1CON** should close. The amber **POWER ON** LED on the Diagnostic Display Panel should light.

For 12 & 16 Amp Drives, **DS1** the "bus charged" light on Power Distribution Board A2 should light.

For 22-96 Amp Drives, **DS1** the "bus indicator" light on Bus Indicator Board A41 should light.

Step 3 If the Drive is equipped with Manual Bypass Control, AC line phase must be established for correct motor rotation when in drive and bypass.

Set the **DRIVE/OFF/BYPASS** switch or customer supplied control to **DRIVE**. Set the speed pot or speed reference to 10% speed. Check motor rotation by pressing the **START** pushbutton, then the **STOP** pushbutton as the motor just begins to rotate.

5.1
Initial Operation
(continued)

If the motor runs backwards, wait for the motor to coast-to-stop, **remove input power to the Drive at the disconnect device** and wait (60) seconds. Reverse direction by switching any two motor leads at **101TB** on the Option Mounting Panel.

Set the **DRIVE/OFF/BYPASS** switch or customer supplied control to **BYPASS**. Check motor rotation by pressing the **START** pushbutton, then the **STOP** pushbutton as the motor just begins to rotate.

If the motor runs backwards, wait for the motor to coast-to-stop, **remove input power to the Drive at the disconnect device** and wait (60) seconds. Reverse direction by switching any two of the AC line input leads at the Drive disconnect device.

Step 4 If the Drive is not equipped with Manual Bypass Control, set the speed pot or speed reference to 10% speed. Check for correct motor rotation by pressing the **START** pushbutton, then the **STOP** pushbutton as the motor just begins to rotate.

If the motor runs backwards, wait for the motor to coast-to-stop, **remove input power to the Drive at the disconnect device** and wait (60) seconds. To reverse direction, switch any two motor leads at:

101TB if the Options Mounting Panel Is Installed

For 12 & 16 Amp Drives, TB2 if the Options Mounting Panel Is Not Installed

For 22-96 Amp Drives, 2TB if the Options Mounting Panel Is Not Installed

Once Correct Rotation Has Been Established

Step 1 Set the **Speed Pot** to **MINIMUM** (fully CCW). Should a minimum speed other than 0 Hz be required, refer to section 5.3.1, **MIN Speed Pot R26** adjustment.

Step 2 If required, reapply power to the Drive at the disconnect device. Press the **START** pushbutton and slowly turn the speed pot CW. The motor should turn and not trip out. Should the Drive trip, refer to **Appendix E, F, G or H, Bulletin 1335 Troubleshooting**, before resetting the Drive.

Step 3 Press the **STOP** pushbutton. Restart the Drive and check the motor current at several different speed settings. Currents above the motor rated full load current may seriously damage the motor windings if they are permitted to flow continuously for approximately (1) minute. If required, refer to **Appendix E, F, G or H, Bulletin 1335 Troubleshooting**.



IMPORTANT

Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.

5.2
Bulletin 1335
Drive Data Log Sheets

The information below and on the following page should be filled in prior to making any Drive field changes. Any readjustment of Drive factory settings or option changes should be recorded here and on the following page.

Drive Nameplate Data

| | | |
|---|-------|---|
|   | | BULLETIN 1335 ADJUSTABLE FREQUENCY MOTOR DRIVE 56L6 LISTED INDUSTRIAL CONTROL EQUIPMENT |
| SERIAL NO. _____ CATALOG NO. <u>1335-</u> | | |
| | INPUT | OUTPUT |
| VOLTS | | |
| AMPS | | |
| PHASE | | |
| KVA | | |
| FREQ | | |

THE STANDARD UNIT DOES NOT PROVIDE
MOTOR OVERLOAD PROTECTION IN
ACCORDANCE WITH NEC.

Motor Nameplate Data

Mfg. : _____

Frame : _____ Type : _____

HP : _____

Volts : _____

Amps : _____

Hertz : _____

RPM : _____

Temp. Rise : _____

Modulator Logic Board **POTENTIOMETER** SETTINGS

☐ MAX Speed Pot R25 – set for _____

☐ MIN Speed Pot R26 – set for _____

Modulator Logic Board **SWITCH** SETTINGS

☐ ACCEL SWITCH S1 – set for _____ Hz/Sec

☐ DECEL SWITCH S2 – set for _____ Hz/Sec

☐ DC BOOST SWITCH S3 – set for _____ Volts

Modulator Logic Board **JUMPER** SETTINGS

☐ 90/200 Frequency Range Jumper – set for 90

☐ H BST/L BST Jumper – set for _____

☐ RTD S/OFF Jumper – set for OFF

☐ STD/THRD Jumper – set for STD

☐ IFB/XFB Jumper – set for IFB

☐ REV/NO REV Jumper – set for NO REV

☐ VCO/EXT-C Jumper – set for _____

☐ V/Hz Jumper – set for _____

☐ NORM/DEC HOLD Jumper – set for _____

12 & 16 Amp Driver Board **JUMPER** SETTINGS

☐ Overload Current Limit Threshold Adjustment

Jumpers S100 & S101 set for _____ A, position _____

Jumpers S200 & S201 set for _____ A, position _____

Jumpers S300 & S301 set for _____ A, position _____

22 & 28 Amp Driver Board **JUMPER** SETTINGS

☐ Overload Current Limit Threshold Adjustment

A3A Jumpers S1 & S2 set for _____ A, position _____

A3B Jumpers S1 & S2 set for _____ A, position _____

A3C Jumpers S1 & S2 set for _____ A, position _____

Factory Installed Options

[illegible]

Customer Installed Options

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

5.3
Adjustment Procedures

Once initial operation has been verified and the Bulletin 1335 Drive Data Log Sheets filled in, the motor should be connected to the load and the Drive operated under load conditions. All Drive setup adjustments, with the exception of the overload current limit threshold level adjustment, are located on the Modulator Logic Board. The following adjustments must be made to conform to your specific load requirements and any options installed in your Drive.

MAX Speed Pot R25

MIN Speed Pot R26

ACCEL & DECEL Rate Adjustments

DC Boost Adjustment

Additional settings and adjustments may be required. Refer to the following information and any additional option instructions included with your Drive for final setup procedures.

5.3.1
Modulator Logic Board
Potentiometer Settings



CAUTION

Potentiometers **R19** – Over Voltage Trip Adjust, and **R124** – Voltage Sense Adjust, which have been factory set and sealed, *must not* be readjusted. Readjustment of these pots may cause damage to the motor and/or Drive.



MAX Speed Pot R25

Normally Set to 60 Hz at the Factory. Sets the Drive maximum speed when the Drive speed is controlled from the Manual Speed Pot, or the BCD Interface Card, Option G4.



MIN Speed Pot R26

Normally Set to 0 Hz at the Factory. Independent of **MAX Speed**. Sets the Drive minimum speed when the Drive speed is controlled from the Manual Speed Pot.

IMPORTANT

If the **Isolated Signal Conditioner Card** (option or N or N4) is installed, the **MIN** and **MAX** speed pots are inoperative when the **AUTO** mode has been selected on the Isolated Signal Conditioner Card.

If the **BCD Interface Card** (option G4) has been installed, the **MIN** speed pot on the card is inoperative when the **AUTO** mode has been selected.




figure 5.3.1 – Modulator Board A1

5.3.2
Modulator
Logic Board Jumper Settings

∩ 90/200 Frequency
Range Jumper Selection

Normally set to **90** Hz at the Factory. Sets the Drive operating frequency range for either 0-90 Hz or 0-200 Hz.

∩ STD/THRD Jumper

Set to **STD** (standard) at the Factory. This jumper must always be set to the **STD** (standard) position to ensure correct Drive operation. Consult your nearest Allen-Bradley Sales/Support Office should the **THRD** position be required.

∩ IFB/XFB Jumper

Set to **IFB** at the Factory. This jumper must always be set to the **IFB** (internal feedback) position to ensure correct Drive frequency output. Consult your nearest Allen-Bradley Sales/Support Office should the **XFB** position be required.

∩ RTD S/OFF

Set to **OFF** at the Factory. This jumper must always be set to the **OFF** (coast-to-stop) position to ensure correct Drive operation. Consult your nearest Allen-Bradley Sales/Support Office should the **RTD S** position be required.

∩ REV/NO REV Jumper

Set to **NO REV** at the Factory. This jumper must always be set to the **NO REV** (no reverse) position to ensure correct Drive operation. Consult your nearest Allen-Bradley Sales/Support Office should the **REV** position be required.

∩ V/Hz Jumper

Normally Set to **B** at the Factory. If option L, The Function Expander Card or the Euro Card is used, the volts-per-hertz jumper must be removed, otherwise it is set for **A** or **B**.

In the **A** position, the Drive will produce an output of 230V at 60 Hz and 460V at 120 Hz — 3.8 Volts-per-Hertz.

In the **B** position, the Drive will produce 460V at 60 Hz — 7.6 Volts-per-Hertz.

Once the output V/Hz has been established by setting the V/Hz jumper, it can still be affected by:

- *Setting the **H BST/L BST** Jumper and **Switch S3 – DC Boost***
- *Variations in Drive Input Line Voltage*
- *Operating the Drive at Frequencies Above the Frequency at Which Maximum Voltage Occurs*

Or any combination of the above.

∩ H BST/L BST Jumper Selection

Normally Set to **L BST** at the Factory. Sets the Drive DC boost range for either 0-20 volts (low boost – **L BST**) or 0-34 volts (high boost – **H BST**).

∩ VCO/EXT-C Jumper

Normally Set to **VCO** (voltage controlled oscillator) at the Factory. In the **VCO** position it connects the manual speed reference to the speed control circuit. The **EXT-C** position is used with option N or N4, the Isolated Signal Conditioner Card. It allows the option card to supply the frequency reference to the Drive.

5.3.2 Modulator Logic Board Jumper Settings (continued)

NORM/DEC HOLD Jumper

Normally set to **DEC HOLD** (Deceleration Hold). Used to avoid overvoltage trips during deceleration of high inertia or regenerative loads.

In **DEC HOLD** the DC bus voltage is monitored by the Decel Hold circuit for a high voltage condition. If a high voltage condition is sensed — usually caused by decelerating a high inertia load too quickly — the deceleration of the Drive will be paused until the bus voltage decreases. Whenever the Decel Hold circuit is active, LED **CR53 FREQ HOLD** on the Modulator Logic Board will light.

In **NORM** the deceleration hold circuit is disabled. If a high Bus voltage occurs, the Drive will continue at the set deceleration rate. If the Bus voltage rises to the overvoltage trip level, the Drive will trip on an overvoltage fault. The **OVER VOLTS** fault LED will light at the diagnostic display but the **FREQ HOLD** will not be lit.

1. If the **OVERLOAD**, or **PROT. A, B** or **C** LED comes on during deceleration, a reduction in the DC boost setting and/or a slower Decel rate may correct the problem.
2. If an **OVER VOLTS** fault trip occurs during deceleration and selecting **DEC HOLD** or a slower decel rate does not correct the problem, refer to **Appendix E, F, G** or **H, Bulletin 1335 Troubleshooting**, before resetting the Drive. Should the Drive trip again, consult your nearest Allen-Bradley Sales/Support Office for additional information.

5.3.3 Modulator Logic Board Switch Settings



S1 ACCEL and S2 DECEL Rate Adjustments

Both S1 and S2 are (6) position **ON/OFF** designated slide switches that select the **ACCEL** and **DECEL** rates within the range of 1.2 Hz/Sec to 152.4 Hz/Sec. **ACCEL** and **DECEL** rates are binary weighted as follows. Sliding a given switch from the **ON** to the **OFF** position produces a faster rate of change.

| BIT WEIGHTS | |
|----------------|-------------|
| • POSITION 1 = | 2.4 Hz/Sec |
| • POSITION 2 = | 4.8 Hz/Sec |
| • POSITION 3 = | 9.6 Hz/Sec |
| • POSITION 4 = | 19.2 Hz/Sec |
| • POSITION 5 = | 38.4 Hz/Sec |
| • POSITION 6 = | 76.8 Hz/Sec |

IMPORTANT

- 1) If an **OVERLOAD** fault trip occurs during **ACCEL** and readjustment of the DC boost does not prevent the fault trip from reoccurring, a slower **ACCEL** rate may be required.
- 2) If the **OVERLOAD** LED comes on or a phase protect trip occurs during **DECEL**, the **DEC HOLD** function and a reduction in the DC boost setting and/or a slower **DECEL** rate may correct the problem.
- 3) If an **OVER VOLTS** fault trip occurs during **DECEL** and a slower decel rate or the **DEC HOLD** function does not correct the problem, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for additional information.

5.3.3 Modulator Logic Board Switch Settings (continued)

Setting The ACCEL and DECEL Rates


The rates shown below are accurate when a speed command from a BCD Interface Card (option G4) is used. When an analog speed reference is used, total **ACCEL/DECEL** time will be 0.5 to 1.6 seconds longer than rates shown due to an RC type exponential tapering into the new speed.



CAUTION

Never set switches using a ball point pen or pencil. Switches contaminated with conductive debris may cause erratic Drive behavior.

| 1 | 2 | 3 | 4 | 5 | 6 | Hz/Sec |
|-----|-----|----|----|----|----|--------|
| ON | ON | ON | ON | ON | ON | 1.2 |
| OFF | ON | ON | ON | ON | ON | 3.6 |
| ON | OFF | ON | ON | ON | ON | 6.0 |
| OFF | OFF | ON | ON | ON | ON | 8.4 |



| | | | | | | |
|-----|-----|-----|-----|-----|----|------|
| ON | ON | OFF | ON | ON | ON | 10.8 |
| OFF | ON | OFF | ON | ON | ON | 13.2 |
| ON | OFF | OFF | ON | ON | ON | 15.6 |
| OFF | OFF | OFF | ON | ON | ON | 18.0 |
| ON | ON | ON | OFF | ON | ON | 20.4 |
| OFF | ON | ON | OFF | ON | ON | 22.8 |
| ON | OFF | ON | OFF | ON | ON | 25.2 |
| OFF | OFF | ON | OFF | ON | ON | 27.6 |
| ON | ON | OFF | OFF | ON | ON | 30.0 |
| OFF | ON | OFF | OFF | ON | ON | 32.4 |
| ON | OFF | OFF | OFF | ON | ON | 34.8 |
| OFF | OFF | OFF | OFF | ON | ON | 37.2 |
| ON | ON | ON | ON | OFF | ON | 39.6 |
| OFF | ON | ON | ON | OFF | ON | 42.0 |
| ON | OFF | ON | ON | OFF | ON | 44.4 |
| OFF | OFF | ON | ON | OFF | ON | 46.8 |
| ON | ON | OFF | ON | OFF | ON | 49.2 |
| OFF | ON | OFF | ON | OFF | ON | 51.6 |
| ON | OFF | OFF | ON | OFF | ON | 54.0 |
| OFF | OFF | OFF | ON | OFF | ON | 56.4 |
| ON | ON | ON | OFF | OFF | ON | 58.5 |
| OFF | ON | ON | OFF | OFF | ON | 61.2 |
| ON | OFF | ON | OFF | OFF | ON | 63.6 |

| 1 | 2 | 3 | 4 | 5 | 6 | Hz/Sec |
|-----|-----|-----|-----|-----|-----|--------|
| OFF | OFF | ON | OFF | OFF | ON | 66.0 |
| ON | ON | OFF | OFF | OFF | ON | 68.4 |
| OFF | ON | OFF | OFF | OFF | ON | 70.8 |
| ON | OFF | OFF | OFF | OFF | ON | 73.2 |
| OFF | OFF | OFF | OFF | OFF | ON | 75.6 |
| ON | ON | ON | ON | ON | OFF | 78.0 |
| OFF | ON | ON | ON | ON | OFF | 80.4 |
| ON | OFF | ON | ON | ON | OFF | 82.8 |
| OFF | OFF | ON | ON | ON | OFF | 85.2 |
| ON | ON | OFF | ON | ON | OFF | 87.6 |
| OFF | ON | OFF | ON | ON | OFF | 90.0 |
| ON | OFF | OFF | ON | ON | OFF | 92.4 |
| OFF | OFF | OFF | ON | ON | OFF | 94.8 |
| ON | ON | ON | OFF | ON | OFF | 97.2 |
| OFF | ON | ON | OFF | ON | OFF | 99.6 |
| ON | OFF | ON | OFF | ON | OFF | 102.0 |
| OFF | OFF | ON | OFF | ON | OFF | 104.4 |
| ON | ON | OFF | OFF | ON | OFF | 106.8 |
| OFF | ON | OFF | OFF | ON | OFF | 109.2 |
| ON | OFF | OFF | OFF | ON | OFF | 111.6 |
| OFF | OFF | OFF | OFF | ON | OFF | 114.0 |
| ON | ON | ON | ON | OFF | OFF | 116.4 |
| OFF | ON | ON | ON | OFF | OFF | 118.8 |
| ON | OFF | ON | ON | OFF | OFF | 121.2 |
| OFF | OFF | ON | ON | OFF | OFF | 123.6 |
| ON | ON | OFF | ON | OFF | OFF | 126.0 |
| OFF | ON | OFF | ON | OFF | OFF | 128.4 |
| ON | OFF | OFF | ON | OFF | OFF | 130.8 |
| OFF | OFF | OFF | ON | OFF | OFF | 133.2 |
| ON | ON | ON | OFF | OFF | OFF | 135.6 |
| OFF | ON | ON | OFF | OFF | OFF | 138.0 |
| ON | OFF | ON | OFF | OFF | OFF | 140.4 |
| OFF | OFF | ON | OFF | OFF | OFF | 142.8 |
| ON | ON | OFF | OFF | OFF | OFF | 145.2 |
| OFF | ON | OFF | OFF | OFF | OFF | 147.6 |
| ON | OFF | OFF | OFF | OFF | OFF | 150.0 |
| OFF | OFF | OFF | OFF | OFF | OFF | 152.4 |


5.3.3 Modulator Logic Board Switch Settings (continued)

S3 DC Boost Adjustment

S3 works in conjunction with the **H BST/L BST** jumper to set the Drive DC boost. Switch S3 consists of (4) rocker switches which allow up to (16) possible DC boost settings.

IMPORTANT

Two types of rocker switches are used on the Modulator Logic Board. The switch illustrated below adds more boost when the switch is rocked to **OPEN**. The alternate switch is **CLOSED** when the number on the switch is depressed.




| | | | | BOOST VOLTS | |
|-------|-------|-------|-------|-------------|-------|
| | | | | L BST | H BST |
| 1 | 2 | 3 | 4 | 0 | 0 |
| CLOSE | CLOSE | CLOSE | CLOSE | 0 | 0 |
| OPEN | CLOSE | CLOSE | CLOSE | 1.33 | 2.27 |
| CLOSE | OPEN | CLOSE | CLOSE | 2.67 | 4.53 |
| OPEN | OPEN | CLOSE | CLOSE | 4.00 | 6.80 |
| CLOSE | CLOSE | OPEN | CLOSE | 5.33 | 9.07 |
| OPEN | CLOSE | OPEN | CLOSE | 6.67 | 11.33 |
| CLOSE | OPEN | OPEN | CLOSE | 8.00 | 13.60 |
| OPEN | OPEN | OPEN | CLOSE | 9.33 | 15.90 |
| CLOSE | CLOSE | CLOSE | OPEN | 10.70 | 18.10 |
| OPEN | CLOSE | CLOSE | OPEN | 12.00 | 20.40 |
| CLOSE | OPEN | CLOSE | OPEN | 13.30 | 22.70 |
| OPEN | OPEN | CLOSE | OPEN | 14.70 | 24.90 |
| CLOSE | CLOSE | OPEN | OPEN | 16.00 | 27.20 |
| OPEN | CLOSE | OPEN | OPEN | 17.30 | 29.50 |
| CLOSE | OPEN | OPEN | OPEN | 18.70 | 31.70 |
| OPEN | OPEN | OPEN | OPEN | 20.00 | 34.00 |

Adding DC Boost

Generally, less DC boost is required as developed motor HP and efficiency increases and starting torque demand decreases. Conversely, more DC boost is required as HP decreases, motor efficiency decreases, and starting load torque increases.


Too little boost will cause the motor to draw more in-phase current, while too much boost may increase the magnetizing current to the motor to the point of saturation. Generally, the best DC boost setting is the lowest value that will consistently start the load. Start with zero boost and increase the setting until capable of developing the required breakaway or starting torque.

5.3.3
Modulator Logic Board
Switch Settings
(continued)



Decelerating a large inertia load with excessive DC boost may cause the Drive to go into **OVERLOAD** (current limit) or experience a phase protect fault trip due to saturation of the motor.

Reducing the DC boost and/or using a slower DECEL rate will usually correct the problem. Reducing the DC boost however, may reduce the motor's ability to start the load. Should this occur, contact your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.



**5.3.4
Driver Board
Jumper Settings**

IMPORTANT

Driver Board Jumpers for 12-28 Amp ratings have been preset at the factory at the amp rating specified on the Drive Nameplate. Field adjustment should not be necessary. Should the Driver Board require replacement, the jumpers should be set as described below and on the following pages prior to installation.

There are no adjustment settings for Bulletin 1335 36-96 Amp Driver Boards, however 56-96 Amp Driver Board provide fuse status indication as described in **Appendix G** or **H**.

**□ 12 & 16 Amp
Overload Current Limit
Threshold Level Adjustment**

There are two jumpers for each section of the Driver Board – **S100 & S101** for **SECTION A**, **S200 & S201** for **SECTION B**, **S300 & S301** for **SECTION C**. These jumpers establish the threshold level at which the **OVERLOAD** (current limit) function becomes active.

All jumpers must be set to the same position as shown in **figure 5.3.4a** to correspond to either a 12 or 16 Amp Drive. For 12 Amp Drives, all jumpers on this board should be set to the “**A**” position. For 16 Amp Drives, all jumpers should be set to the “**B**” position.

**□ 22 & 28 Amp
Overload Current Limit
Threshold Level Adjustment**

There are two jumpers, **S1 & S2**, for each of the three Driver Boards, **A3A, A3B, & A3C**. These jumpers establish the threshold level at which the **OVERLOAD** (current limit) function becomes active.

All jumpers must be set to the same position as shown in **figure 5.3.4b** on each board to correspond to either a 22 or 28 Amp Drive.




figure 5.3.4a - 12 & 16 Amp Driver Board




figure 5.3.4b - P/N 50399 - 22 & 28 Amp Driver Board

Bulletin 1335 Operation

6.0 Operating Considerations

The Bulletin 1335 Variable Torque AC Drive provides a three phase motor with variable frequency and voltage utilizing PWM (Pulse Width Modulated) technology. Varying the frequency of the applied power to the motor varies the speed of the motor.

The Bulletin 1335 Drive is designed for use with variable torque, square law and cubed law loads. With square law loads, the torque varies directly with the change in speed while the horsepower varies as the square of the speed change. With cubed law loads, the torque varies as the square of the speed change while the horsepower varies as the cube of the speed change.

Typical examples of square law loads are:

- Some Positive Displacement Pumps
- Some Extruders and Some Mixers

Typical examples of cube law loads are:

- Some Centrifugal Pumps
- Fans and Blowers.

Regardless of whether your application is a square law or cube law load, sizing of the Bulletin 1335 Drive should be based upon the motor load current required at maximum operating speed. Caution is advised in going above motor base (nameplate) speed in these applications.




figure 6.0 – Square & Cube Law Load Curves

Bulletin 1335 380/415V Specifications & Adjustments

7.0 380V Specification Table

| Model and Ratings 12 & 16 Amp 22, 28 & 36 Amp | Model Number | 1335-D _ N | 1335-E _ N | 1335-F _ N | 1335-G _ N | 1335-R _ N |
|---|------------------|------------|------------|------------|------------|------------|
| | Output Amps | 12.0 | 16.0 | 22.0 | 28.0 | 36.0 |
| | Output Voltage | 0-380 | 0-380 | 0-380 | 0-380 | 0-380 |
| | Output KVA | 7.9 | 10.5 | 14.5 | 18.4 | 23.7 |
| | Input Amps | 10.5 | 14.0 | 19.3 | 25.3 | 33.6 |
| | Input Voltage | 380 | 380 | 380 | 380 | 380 |
| | Input kVA | 6.9 | 9.2 | 12.7 | 16.7 | 22.1 |
| | Output Frequency | 0-200 | 0-200 | 0-200 | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 | 50 | 50 | 50 |

| Model and Ratings 56 & 69 Amp | Model Number | 1335-J _ N | 1335-K _ N |
|--|------------------|------------|------------|
| | Output Amps | 56.0 | 69.0 |
| | Output Voltage | 0-380 | 0-380 |
| | Output KVA | 36.9 | 45.4 |
| | Input Amps | 52.4 | 63.5 |
| | Input Voltage | 380 | 380 |
| | Input kVA | 34.5 | 41.8 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 |

| Model and Ratings 77 & 96 Amp | Model Number | 1335-L _ N | 1335-N _ N |
|--|------------------|------------|------------|
| | Output Amps | 77.0 | 96.0 |
| | Output Voltage | 0-380 | 0-380 |
| | Output KVA | 50.7 | 63.2 |
| | Input Amps | 70.8 | 88.2 |
| | Input Voltage | 380 | 380 |
| | Input kVA | 46.6 | 58.0 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 |

| | |
|--------------------------------|---|
| Power Supply | Input Voltage — 380V, 3Ø, ±10% Input Frequency — 50 Hz, ±2% |
| Output Volts-per-Hertz | 7.6V/Hz (380V at 50 Hz) with Eurocard or Function Expander Card Installed |
| DC Boost Adjustment | 0-28 Volts |
| Input Under Voltage Protection | 342 Volts Nominal |

7.1
415V Specification Table

| Model and Ratings 12 & 16 Amp 22, 28 & 36 Amp | Model Number | 1335-D _ W | 1335-E _ W | 1335-F _ W | 1335-G _ W | 1335-R _ W |
|---|------------------|------------|------------|------------|------------|------------|
| | Output Amps | 12.0 | 16.0 | 22.0 | 28.0 | 36.0 |
| | Output Voltage | 0-415 | 0-415 | 0-415 | 0-415 | 0-415 |
| | Output KVA | 8.6 | 11.5 | 15.8 | 20.1 | 25.9 |
| | Input Amps | 10.5 | 14.0 | 19.3 | 25.3 | 33.6 |
| | Input Voltage | 415 | 415 | 415 | 415 | 415 |
| | Input kVA | 7.5 | 10.1 | 13.9 | 18.2 | 24.2 |
| | Output Frequency | 0-200 | 0-200 | 0-200 | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 | 50 | 50 | 50 |

| Model and Ratings 56 & 69 Amp | Model Number | 1335-J _ W | 1335-K _ W |
|--|------------------|------------|------------|
| | Output Amps | 56.0 | 69.0 |
| | Output Voltage | 0-415 | 0-415 |
| | Output KVA | 40.3 | 49.6 |
| | Input Amps | 52.4 | 63.5 |
| | Input Voltage | 415 | 415 |
| | Input kVA | 37.7 | 45.6 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 |

| Model and Ratings 77 & 96 Amp | Model Number | 1335-L _ W | 1335-N _ W |
|--|------------------|------------|------------|
| | Output Amps | 77.0 | 96.0 |
| | Output Voltage | 0-415 | 0-415 |
| | Output KVA | 55.3 | 69.0 |
| | Input Amps | 70.8 | 88.2 |
| | Input Voltage | 415 | 415 |
| | Input kVA | 50.9 | 63.4 |
| | Output Frequency | 0-200 | 0-200 |
| | Input Frequency | 50 | 50 |

| | |
|--------------------------------|---|
| Power Supply | Input Voltage — 415V, 3Ø, ±10% Input Frequency — 50 Hz, ±2% |
| Output Volts-per-Hertz | 8.3V/Hz (415V at 50 Hz) with Eurocard or Function Expander Card Installed |
| DC Boost Adjustment | 0-31 Volts |
| Input Under Voltage Protection | 373 Volts Nominal |

7.2 Adjustments

The Bulletin 1335 Variable Torque Drive has the capability of operating from AC input line voltages of 380 or 415V only when the following adjustments are made to the Drive.

- The Drive power, control and fan transformers must be re-tapped to the correct voltage levels.
- If installed, Option M2, the Auxiliary Control Transformer must be re-tapped to the correct voltage level.
- Either the Eurocard or the Function Expander Card must be installed to produce the correct volts-per-hertz output from the Drive.

Unless the Drive is ordered from the factory as a 380 or 415V unit, the following adjustments must be made.

7.2.1 Transformer Adjustments

Determine the model number of the Drive to be modified from the Drive nameplate, then determine the number and location of the transformers that require re-tapping from the information below. If option M2, the Auxiliary Control Transformer is installed, refer to the option information and connection drawings supplied with the Drive.

As shown in the **Drive Schematics** in **Appendixes I-L**, the transformers are normally set for 460V operation, but have 460/415/380V primary taps. All standard transformer primaries are marked as follows.

| | | TAP # | VOLTAGE | |
|--|--|-------|---------------------------|--|
| | | 1 | COMMON — For All Voltages | |
| | | 2 | 380V AC Input | |
| | | 3 | 415V AC Input | |
| | | 4 | 460V AC Input | |

| MODEL | TRANSFORMER | LOCATION REFERENCE | SCHEMATIC REFERENCE |
|--------------------|--------------|--------------------|---------------------|
| 1335-D __ (12 Amp) | 1T | Appendix A | Appendix I |
| 1335-E __ (16 Amp) | 1T | Appendix A | Appendix I |
| 1335-F __ (22 Amp) | 1T & 2T | Appendix B | Appendix J |
| 1335-G __ (28 Amp) | 1T & 2T | Appendix B | Appendix J |
| 1335-R __ (36 Amp) | 1T, & 2T | Appendix B | Appendix J |
| 1335-J __ (56 Amp) | 1T, 2T, & 3T | Appendix C | Appendix K |
| 1335-K __ (69 Amp) | 1T, 2T, & 3T | Appendix C | Appendix K |
| 1335-L __ (77 Amp) | 1T, 2T, & 3T | Appendix D | Appendix L |
| 1335-N __ (96 Amp) | 1T, 2T, & 3T | Appendix D | Appendix L |

7.2.2
Volts-per-Hertz Adjustment

For the Drive to produce the correct volts-per-hertz at either 380 or 415V, the V/Hz jumper located on the Modulator Logic Board must be unplugged and removed from the board (jumper location is shown in **figure 5.3.1, Chapter 5**). Once the jumper has been removed, either the Eurocard or Option L — the Function Expander Card — must then be installed in the Drive. Either card plugs onto Modulator Logic Board connector **J104**. If the Eurocard is used, additional volts-per-hertz adjustments are not required. If the Function Expander Card is used, follow the instructions provided with the kit to complete installation. Note all changes made to the Drive on both the **Drive Data Log Sheets, Section 5.2**, and on the Drive Nameplate in the Drive. Follow the installation and adjustment procedures as outlined in **Chapters 4 & 5**.

A

Bulletin 1335 12 & 16 Amp Component Index

12 & 16 Amp Recommended Spare Parts

| Description | Identification | Part № | Value | Used On | Recommended Stock |
|--------------------------|----------------|------------------|--------------------------------------|--------------------|-------------------|
| Modulator Logic Board | A1 | <u>50387-002</u> | — | <u>All Ratings</u> | 1 |
| Power Distribution Board | A2 | 50906 | — | 12 & 16 Amp | 1 |
| Driver Board | A3 | 50905-002 | — | 12 & 16 Amp | 1 |
| Diagnostic Board | A7 | <u>50382</u> | — | <u>All Ratings</u> | 0 |
| Fuse | F1, F2, F3 | 200935 | 15A, 600V (KTK 10) | 12 Amp | 6 |
| | | 201925 | 20A, 600V (KTK 12) | 16 Amp | 6 |
| Fuse | F4, F5 | 101775 | 0.6A, 500V (FNQ 6/10 or ATQ 6/10) | 12 & 16 Amp | 2 |
| Bus Capacitor | 2C, 3C | 201906 | 1400 μ F, 450V DC | 12 & 16 Amp | 1 |
| Control Transformer | 1T | 91854 | — | 12 & 16 Amp | 0 |
| MOV Assembly | MOV 4 | 40401 | — | 12 & 16 Amp | 0 |
| Inductor | 1L | 91864 | 2.9mH, 11.2A | 12 Amp | 0 |
| | | 91865 | 2.2mH, 14.9A | 16 Amp | 0 |
| Inductor | 2L | 91849 | 15mH, 1.3A | 12 & 16 Amp | 0 |
| Power Switching Module | 1Q, 2Q, 3Q | 202099 | — | 12 & 16 Amp | 1 |
| Snubber Assembly | 1SN, 2SN, 3SN | 40410 | — | 12 & 16 Amp | 0 |
| Temperature Sensor | 1TAS | 201667 | — | 12 & 16 Amp | 0 |
| Rectifier Assembly | 1REC | 201525 | — | 12 & 16 Amp | 1 |

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

12 & 16 Amp Component Access & Location




CAUTION

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-




Diagnostic Board
A7

12 & 16 Amp Component Access & Location

(Power Distribution Board A2)

- Step 1** Disconnect molex connectors **J201**, **J203**, & **J204** and berg connector **J205** at Power Distribution Board A2.
- Step 2** Disconnect push on connectors **E13**, **E16**, **E17**, **E21** & **E22** from Power Distribution Board A2.
- Step 3** Remove the (4) nylon thumb screws from the board.
- Step 4** Lift up the (2) latch fasteners at the bottom of the board. The Power Distribution Board will now be free to swing up.




12 & 16 Amp Component Access & Location

Step 5 To lock the Power Distribution Board in the raised position, tighten the phillips head screws (or wing nuts), on the board's (2) locking hinges. To lower the Power Distribution Board, back off the screws (or wing nuts) $\frac{1}{2}$ - turn.

(Driver Board A3)

Step 6 To remove Driver Board A3, disconnect moxex connectors J302A, J302B, & J302C and berg connector J301 at the board.

Step 7 Release the (6) $\frac{1}{4}$ - turn standoffs as shown. The Driver Board may now be lifted out.



12 & 16 Amp Component Access & Location

Temperature Sensor 1TAS

Rectifier Assembly 1REC

Snubber Assemblies 1SN, 2SN & 3SN

Power Switching Modules 1Q, 2Q & 3Q

Resistors 2R & 3R


Inductors 1L & 2L

MOV4 Assembly


Transformer 1T

Bus Capacitors 2C & 3C


Wiring connections to the above components are shown on the following pages.



12 & 16 Amp Component Location & Wiring



12 & 16 Amp Component Location & Wiring



12 & 16 Amp Component Wiring List

As shown on page A-3, wires going to interconnection points **E1**, **E2**, & **E5-22**, are marked and color coded on Power Distribution Board A2. These same points are referenced in the troubleshooting procedures for your Drive in Appendix E. These points may be accessed by slightly lifting up the insulated connectors.

| COLOR | to | from |
|--------|--|--------------------------------------|
| gray | Control Transformer 1T (pin 6) | Power Distribution Board E1 |
| green | Chassis Ground | Power Distribution Board E2 |
| blue | Power Switching Module 3Q (C2/E1) | Power Distribution Board E5 |
| green | Power Switching Module 2Q (C2/E1) | Power Distribution Board E6 |
| violet | Power Switching Module 1Q (C2/E1) | Power Distribution Board E7 |
| red | Rectifier Assembly 1 REC (AC3) | Power Distribution Board E8 |
| brown | Rectifier Assembly 1 REC (AC2) | Power Distribution Board E9 |
| black | Rectifier Assembly 1 REC (AC1) | Power Distribution Board E10 |
| brown | Control Transformer 1T (pin 1) | Power Distribution Board E11 |
| green | Control Transformer 1T (pin 4) | Power Distribution Board E12 |
| red | - BUS | Power Distribution Board E13 |
| green | Temperature Sensor 1TAS | Power Distribution Board E14 |
| black | Temperature Sensor 1TAS | Power Distribution Board E15 |
| black | Inductor 1L (pin 2) | Power Distribution Board E16 |
| green | Bus Capacitor 2C (+) | Power Distribution Board E17 |
| white | Control Transformer 1T (pin 7) | Power Distribution Board E18 |
| black | Control Transformer 1T (pin 8) | Power Distribution Board E19 |
| yellow | Control Transformer 1T (pin 9) | Power Distribution Board E20 |
| black | Inductor 2L (pin 1) | Power Distribution Board E21 |
| red | Inductor 2L (pin 2) | Power Distribution Board E22 |
| gray | - BUS | Rectifier Assembly 1REC (-) |
| white | Inductor 1L (pin 1) | Rectifier Assembly 1REC (+) |
| blue | + BUS | Bus Capacitor 2C (+) |
| violet | - BUS | Bus Capacitor 3C (-) |
| black | Bus Capacitor 2C (-) | Bus Capacitor 3C (+) |
| yellow | Bus Capacitor 2C (+) | Resistor 2R |
| blue | Bus Capacitor 3C (+) | Resistor 2R |
| yellow | Bus Capacitor 3C (-) | Resistor 3R |
| blue | Bus Capacitor 3C (+) | Resistor 3R |

B

Bulletin 1335 22, 28 & 36 Amp Component Index

22, 28 & 36 Amp Recommended Spare Parts

| Description | Identification | Part № | Value | Used On | Recommended Stock |
|----------------------------|--------------------|------------------|-----------------------|--------------------|-------------------|
| Modulator Logic Board | A1 | <u>50387-002</u> | — | <u>All Ratings</u> | 1 |
| Driver Board | A3A, A3B, A3C | 50399 | — | 22 & 28 Amp | 1 |
| | | 50399-001 | — | 36 Amp | 1 |
| Voltage Sensing Board | A4 | 50386 | — | 22, 28 & 36 Amp | 0 |
| Logic Power Supply Board | A6 | 50389 | — | 22, 28 & 36 Amp | 1 |
| Diagnostic Board | A7 | <u>50382</u> | — | <u>All Ratings</u> | 0 |
| Output Ground Sensor Board | A8 | 50385 | — | 22, 28 & 36 Amp | 1 |
| Contactor Interface Board | A9 | 50404-001 | — | 22, 28 & 36 Amp | 1 |
| Bus Indicator Board | A41 | 50913 | — | 22, 28 & 36 Amp | 0 |
| Fuse | 1FU, 2FU, 3FU | 201258 | 25A, 600V (JKS 25) | 22 Amp | 6 |
| | | 200384 | 30A, 600V (JKS 30) | 28 Amp | 6 |
| | | 201463 | 50A, 600V (JKS 50) | 36 Amp | 6 |
| Fuse | 4FU, 5FU | 201590 | 1A, 500V (FNQ 1) | 22, 28 & 36 Amp | 4 |
| Fuse | 4FU, 5FU | 248010 | 3A, 500V (FNQ 1) | 22, 28 & 36 Amp | 4 |
| Bus Capacitor | 2C1, 2C2, 3C1, 3C2 | 200364 | 2400 μ F, 450V DC | 22, 28 & 36 Amp | 2 |
| Control Transformer | 1T | 91854 | — | 22, 28 & 36 Amp | 0 |
| Transformer | 2T | 91880 | — | 22, 28 & 36 Amp | 0 |
| Current Transformer | 1CT | 91824 | — | 22, 28 & 36 Amp | 0 |


Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

22, 28 & 36 Amp Recommended Spare Parts
(continued)


| Description | Identification | Part No | Value | Used On | Recommended Stock |
|------------------------|--------------------------------|---------|-----------|-----------------|-------------------|
| MOV Assembly | 1 SUP, 2 SUP, 3 SUP | 41475 | — | 22, 28 & 36 Amp | 1 |
| Inductor | 1L | 91866 | — | 22 Amp | 0 |
| | | 91867 | — | 28 Amp | 0 |
| | | 91871 | — | 36 Amp | 0 |
| Inductor | 2L | 91849 | — | 22, 28 & 36 Amp | 0 |
| Power Switching Module | 1Q1, 2Q1, 3Q1 1Q2, 2Q2, 3Q2 | 202099 | — | 22, 28 & 36 Amp | 2 |
| Temperature Sensor | 1TAS | 201667 | — | 22, 28 & 36 Amp | 0 |
| Rectifier Assembly | 1REC | 201525 | — | 22 & 28 Amp | 1 |
| | 1 REC, 2 REC, 3 REC | 201445 | — | 36 Amp | 2 |
| Precharge Contactor | 1 CON | 201458 | — | 22, 28 & 36 Amp | 0 |
| Resistor Assembly | 1R1, 1R2 | 41469 | 500Ω, 50W | 22, 28 & 36 Amp | 0 |

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.


22, 28 & 36 Amp Drives




22 & 28 Amp Component Location



22 & 28 Amp Component Location




(LEFT HAND PANEL)




(RIGHT HAND PANEL)


36 Amp Component Location



36 Amp Component Location



(LEFT HAND PANEL)



(RIGHT HAND PANEL)

Bulletin 1335 56 & 69 Amp Component Index

56 & 69 Amp Recommended Spare Parts

| Description | Identification | Part № | Value | Used On | Recommended Stock |
|----------------------------|--------------------------------|------------------|-------------------------|--------------------|-------------------|
| Modulator Logic Board | A1 | <u>50387-002</u> | — | <u>All Ratings</u> | 1 |
| Driver Board | A3A, A3B, A3C | 50403 | — | 56 & 69 Amp | 1 |
| Voltage Sensing Board | A4 | 50386 | — | 56 & 69 Amp | 0 |
| Logic Power Supply Board | A6 | 50389 | — | 56 & 69 Amp | 1 |
| Diagnostic Board | A7 | <u>50382</u> | — | <u>All Ratings</u> | 0 |
| Output Ground Sensor Board | A8 | 50385 | — | 56 & 69 Amp | 1 |
| Contactors Interface Board | A9 | 50404-001 | — | 56 & 69 Amp | 1 |
| Driver Power Supply Board | A10 | 50406 | — | 56 & 69 Amp | 1 |
| Bus Indicator Board | A41 | 50913 | — | 56 & 69 Amp | 0 |
| Fuse | 1FU, 2FU, 3FU | 112032 | 100A, 600V (JJS 100) | 56 & 69 Amp | 3 |
| Fuse | 4FU | 201590 | 1A, 500V (FNQ 1) | 56 & 69 Amp | 1 |
| Fuse | 5FU | 201708 | 1.5A, 500V (FNQ 1.5) | 56 & 69 Amp | 1 |
| Fan Fuse | 7FU | 201478 | .2A, 500V (FNQ .2) | 56 & 69 Amp | 0 |
| Bus Fuse | 8FU | 201466 | 125A, 700V (FWP 125) | 56 & 69 Amp | 1 |
| Bus Capacitor | 2C1, 2C2, 2C3 3C1, 3C2, 3C3 | 200364 | 2400µF, 450V DC | 56 & 69 Amp | 1 |
| Snubber Capacitor | 4C, 5C, 6C | 201455 | 10µF, 660V DC | 56 & 69 Amp | 0 |
| Control Transformer | 1T | 91854 | — | 56 & 69 Amp | 0 |
| Transformer | 2T | 91880 | — | 56 & 69 Amp | 0 |
| Fan Transformer | 3T | 91885 | — | 56 & 69 Amp | 0 |
| Current Transformer | 1CT | 91824 | — | 56 & 69 Amp | 0 |


Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

56 & 69 Amp Recommended Spare Parts
(continued)


| Description | Identification | Part № | Value | Used On | Recommended Stock |
|------------------------|--------------------------------|--------|----------|-------------|-------------------|
| MOV Assembly | 1 SUP, 2 SUP, 3 SUP | 41484 | — | 56 & 69 Amp | 1 |
| Inductor | 1L1, 1L2 | 91886 | — | 56 Amp | 0 |
| | | 91874 | — | 69 Amp | 0 |
| Inductor | 2L | 91849 | — | 56 & 69 Amp | 0 |
| Inductor | 3L, 4L, 5L | 91879 | — | 56 & 69 Amp | 0 |
| Power Switching Module | 1Q1, 2Q1, 3Q1 1Q2, 2Q2, 3Q2 | 201411 | — | 56 & 69 Amp | 2 |
| Temperature Sensor | 1TAS | 201667 | — | 56 & 69 Amp | 0 |
| Rectifier Assembly | 1 REC, 2 REC, 3 REC | 201445 | — | 56 & 69 Amp | 1 |
| Precharge Contactor | 1 CON | 201459 | — | 56 & 69 Amp | 0 |
| Fan | 1FN | 201508 | — | 56 & 69 Amp | 0 |
| Snubber Diode | 1D | 201423 | — | 56 & 69 Amp | 0 |
| Resistor Assembly | 1R1, 1R2 | 243426 | 25Ω, 50W | 56 & 69 Amp | 0 |

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

56 & 69 Amp Component Location




56 & 69 Amp Component Location




(BACK PANEL)

56 & 69 Amp Component Location



(LEFT HAND PANEL)



(RIGHT HAND PANEL)

D

Bulletin 1335 77 & 96 Amp Component Index

77 & 96 Amp Recommended Spare Parts

| Description | Identification | Part № | Value | Used On | Recommended Stock |
|----------------------------|--------------------------------|------------------|-------------------------------|--------------------|-------------------|
| Modulator Logic Board | A1 | <u>50387-002</u> | — | <u>All Ratings</u> | 1 |
| Driver Board | A3A, A3B, A3C | 50403 | — | 77 & 96 Amp | 1 |
| Voltage Sensing Board | A4 | 50386 | — | 77 & 96 Amp | 0 |
| Logic Power Supply Board | A6 | 50389 | — | 77 & 96 Amp | 1 |
| Diagnostic Board | A7 | <u>50382</u> | — | <u>All Ratings</u> | 0 |
| Output Ground Sensor Board | A8 | 50385 | — | 77 & 96 Amp | 1 |
| Contactorm Interface Board | A9 | 50404-003 | — | 77 & 96 Amp | 1 |
| Driver Power Supply Board | A10 | 50406 | — | 77 & 96 Amp | 1 |
| Bus Indicator Board | A41 | 50913 | — | 77 & 96 Amp | 0 |
| LEM Board | A42 | 50914-001 | — | 77 Amp | 1 |
| | | 50914-002 | — | 96 Amp | 1 |
| Fuse | 1FU, 2FU, 3FU | 202090 | 150A, 600V (JJS 150) | 77 & 96 Amp | 3 |
| Fuse | 4FU | 201590 | 1A, 500V (FNQ 1) | 77 & 96 Amp | 1 |
| Fuse | 5FU | 201708 | 1.5A, 500V (FNQ 1.5) | 77 & 96 Amp | 1 |
| Fan Fuse | 7FU | 201927 | .5A, 500V (FNQ .5) | 77 & 96 Amp | 0 |
| Bus Fuse | 8FU | 202091 | 150A, 700V | 77 & 96 Amp | 1 |
| Fuse | 9FU | 200816 | 10A, 250V (ABC10 or AGC10) | 77 & 96 Amp | 1 |
| Bus Capacitor | 2C1, 2C2, 2C3 3C1, 3C2, 3C3 | 200364 | 2400µF, 450V DC | 77 & 96 Amp | 1 |
| Snubber Capacitor | 4C, 5C, 6C | 201455 | 10µF, 660V DC | 77 & 96 Amp | 0 |
| Control Transformer | 1T | 91854 | — | 77 & 96 Amp | 0 |
| Transformer | 2T | 121521 | — | 77 & 96 Amp | 0 |
| Fan Transformer | 3T | 91885 | — | 77 & 96 Amp | 0 |
| Current Transformer | 1CT | 91824 | — | 77 & 96 Amp | 0 |


Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

77 & 96 Amp Recommended Spare Parts
(continued)


| Description | Identification | Part № | Value | Used On | Recommended Stock |
|------------------------|--------------------------------|--------|----------|-------------|-------------------|
| MOV Assembly | 1 SUP, 2 SUP, 3 SUP | 41484 | — | 77 & 96 Amp | 1 |
| Inductor | 1L1, 1L2 | 91874 | — | 77 & 96 Amp | 0 |
| Inductor | 2L | 91849 | — | 77 & 96 Amp | 0 |
| Inductor | 3L, 4L, 5L | 91879 | — | 77 & 96 Amp | 0 |
| Power Switching Module | 1Q1, 2Q1, 3Q1 1Q2, 2Q2, 3Q2 | 201411 | — | 77 & 96 Amp | 2 |
| Temperature Sensor | 1TAS | 201667 | — | 77 & 96 Amp | 0 |
| Rectifier Assembly | 1 REC, 2 REC, 3 REC | 201445 | — | 77 & 96 Amp | 1 |
| Precharge Contactor | 1 CON | 202127 | — | 77 & 96 Amp | 0 |
| Fan | 1FN | 201508 | — | 77 & 96 Amp | 0 |
| Snubber Diode | 1D | 201423 | — | 77 & 96 Amp | 0 |
| Resistor Assembly | 1R1, 1R2 | 243426 | 25Ω, 50W | 77 & 96 Amp | 0 |
| LEM Assembly | 1 LEM, 2 LEM, 3 LEM | 202097 | — | 77 & 96 Amp | 0 |

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

77 & 96 Amp Component Location




77 & 96 Amp Component Location




(BACK PANEL)

77 & 96 Amp Component Location



(LEFT HAND PANEL)



(RIGHT HAND PANEL)

Bulletin 1335 12 & 16 Amp Troubleshooting

12 & 16 Amp Diagnostic LED Display

Power ON – Indicates input power is connected when illuminated.

Overload Protection – When constantly illuminated indicates an over current condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.

Under Voltage Protection – When illuminated indicates that the Drive has tripped OFF due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.

Over Voltage Protection – When illuminated indicates that the Drive has tripped OFF due to the bus voltage exceeding 760V DC.

"A" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "A" Phase Output Transistor
- Section "A" of the Driver Board is Malfunctioning

"B" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "B" Phase Output Transistor
- Section "B" of the Driver Board is Malfunctioning

"C" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "C" Phase Output Transistor
- Section "C" of the Driver Board is Malfunctioning

Drive Over Temperature Protection Trip – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.

Output Ground Fault Protection Trip Indication – NOT UTILIZED ON 12 & 16 Amp DRIVES

Symptom
1, 2 & 3

Symptom
4, 5 & 6

Symptom
7



Symptom
8

Symptom
9

Symptom
9

Symptom
9

Symptom
10



Symptom
11

DS1 – Located on Power Distribution Board A2 – When illuminated indicates that the bus potential is in excess of 42V DC.

12 & 16 Amp Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix A** on pages **A-2, A3, A4 & A-5**.

All Drive **interconnection wiring & interconnection points** are illustrated in **Appendix A** on pages **A-6 & A-7**.

All **voltage values & polarities** referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix I** or the Modulator Logic Board Interconnection Diagram in **Appendix M**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the **STOP** pushbutton has been depressed.

If neon light **DS1** on the Power Distribution Board is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (60) seconds, and ensure that DS1 is not lit before servicing.**



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the START Pushbutton Always Ensure:

That the **Speed Pot** or speed reference is set to **MINIMUM**.

That the **AUTO/OFF/MAN Switch** (if present), is in the proper position.

That the **DRIVE/OFF/BYPASS Switch** (if present), is in the proper position.

That the motor is uncoupled from its mechanical load.

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

| Symptom 1 | DIAGNOSTIC PROCEDURE | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|----------|--|---------|--------|--------|--|--------------|----------------|----------|--------------|---------------|----------|--------------|---------------|----------|----------------|-------------|----------|---------------|-------------|----------|---------------|-------------|----------|
| Drive does not start. Amber POWER ON LED is not illuminated. | <p>Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across Input line fuses F1, F2 and F3. Measure voltage across input primary fuse F4. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete STEPS 1, 2 & 3.</p> <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. DS1, the bus charged neon light on Power Distribution Board A2, should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage between connectors E17 (+ BUS) and E13 (– BUS) on Power Distribution Board A2. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> <p>Connections Listed in Steps 2 & 3 are shown on pages A-6 & A-7</p> <p>STEP 2 – Check Rectifier Assembly 1REC.</p> <p>Unplug connectors E8, E9, E10 & E13 at the Power Distribution Board.</p> <p>Unplug connector 1L-1 at Inductor 1L.</p> <p>With an ohmmeter set on the x1 scale, check the resistance of 1REC at the leads as follows.</p> <table><tr><th colspan="2">OHMMETER</th><th>READING</th></tr><tr><th>+ LEAD</th><th>– LEAD</th><th></th></tr><tr><td>1L-1 (1REC+)</td><td>E10 (1REC-AC1)</td><td>INFINITE</td></tr><tr><td>1L-1 (1REC+)</td><td>E9 (1REC-AC2)</td><td>INFINITE</td></tr><tr><td>1L-1 (1REC+)</td><td>E8 (1REC-AC3)</td><td>INFINITE</td></tr><tr><td>E10 (1REC-AC1)</td><td>E13 (1REC–)</td><td>INFINITE</td></tr><tr><td>E9 (1REC-AC2)</td><td>E13 (1REC–)</td><td>INFINITE</td></tr><tr><td>E8 (1REC-AC3)</td><td>E13 (1REC–)</td><td>INFINITE</td></tr></table> <p>If any of the above readings are not as shown, replace Rectifier Assembly 1REC.</p> <div><p>IMPORTANT : When replacing Rectifier Assembly 1REC clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.</p></div> <p>STEP 3 – With the ohmmeter set on the x100 scale, check Bus Capacitors 2C & 3C for a shorted condition as follows.</p> <p>Disconnect leads to Bus Capacitors 2C & 3C .</p> <p>Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (–) NEGATIVE lead of the ohmmeter to the (–) NEGATIVE terminal of the capacitor.</p> <p>The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.</p> <p>After completing STEPS 1, 2 & 3, replace blown fuses and reapply input power.</p> | OHMMETER | | READING | + LEAD | – LEAD | | 1L-1 (1REC+) | E10 (1REC-AC1) | INFINITE | 1L-1 (1REC+) | E9 (1REC-AC2) | INFINITE | 1L-1 (1REC+) | E8 (1REC-AC3) | INFINITE | E10 (1REC-AC1) | E13 (1REC–) | INFINITE | E9 (1REC-AC2) | E13 (1REC–) | INFINITE | E8 (1REC-AC3) | E13 (1REC–) | INFINITE |
| OHMMETER | | READING | | | | | | | | | | | | | | | | | | | | | | | |
| + LEAD | – LEAD | | | | | | | | | | | | | | | | | | | | | | | | |
| 1L-1 (1REC+) | E10 (1REC-AC1) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |
| 1L-1 (1REC+) | E9 (1REC-AC2) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |
| 1L-1 (1REC+) | E8 (1REC-AC3) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |
| E10 (1REC-AC1) | E13 (1REC–) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |
| E9 (1REC-AC2) | E13 (1REC–) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |
| E8 (1REC-AC3) | E13 (1REC–) | INFINITE | | | | | | | | | | | | | | | | | | | | | | | |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|--|--|
| Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated. | <p>Check for line out condition at fuse F3 by measuring the AC line voltage from L3 to either L1 or L2.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across F3. A voltage across F3 indicates that it is open and must be replaced. Before replacing F3, perform STEPS 1, 2 & 3 in Symptom 1, then the following nine steps.</p> <p>STEP 1 – Check precharge circuit fuse F5 for an open condition.</p> <p>STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.</p> <p>STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment R25 or the minimum speed pot adjustment R26 may be ineffective. Refer to section 5.3.1, Minimum and Maximum Speed Adjust.</p> <ul style="list-style-type: none"> ● If option N, N4 or G4 is installed, ensure that: The AUTO/MAN switch on the card is set to the MAN mode. A 1kΩ, 2W, linear taper speed pot has been properly connected to Terminal Block TB1 between terminals 14, 15 & 16. ● If option T14 or T15 is installed, check for continuity across the Motor Overload Relay contact circuit at Terminal Block TB1 between terminals 10 & 11. <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 4 – Check for an open speed pot at Terminal Block TB1. Measure the voltage at Terminal Block TB1 between terminals 14 & 16. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals 14, 15 & 16. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals 15 & 16 should vary from 0 to 3.2V DC. Replace or correct as required.</p> <p>STEP 5 – Check the voltage between terminals 9 & 11 at Terminal Block TB1.</p> <ul style="list-style-type: none"> ● If standard START/STOP configuration is used, there should be 90V AC between terminals 9 & 11. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to TB1. ● If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6. ● If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.4. |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|--|---|
| (continued) | |
| Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated. | <p>STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T. The following voltages should be present at the Power Distribution Board.</p> <p style="padding-left: 40px;">molex connector J204 between pins 4 & 1 14V AC molex connector J204 between pins 2 & 1 14V AC molex connector J204 between pins 5 & 6 15V AC between connector E1 & molex connector J204, pin 1 90V AC between connectors E20 & E19 12V AC between connectors E18 & E19 12V AC</p> <p>If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.</p> <p>STEP 7 – Measure all logic power supply output voltages at the Power Distribution Board. The following voltages should be present at molex connector J203 with respect to Drive common, J203, pin 8. If any one voltage is absent, replace Power Distribution Board A2.</p> <p style="padding-left: 40px;">J203, pin 1 –17V DC J203, pin 5 + 17V DC J203, pin 6 14V AC J203, pin 7 + 11 to + 13V DC (nominal) J203, pin 9 + 11 to + 13V DC (nominal)</p> <p>STEP 8 – Measure contactor K1 supply voltage at Power Distribution Board A2. There should be + 9 to + 15V DC between pins 7 & 10 at molex connector J203. There should also be + 9 to + 15V DC between points 3 & 4 at the contactor. If 9 to 15 volts is measured and K1 is not picked-up, the contactor may be inoperative. If inoperative, replace the Power Distribution Board.</p> <p>STEP 9 – Check pin 10 at molex connector J203 with respect to pin 8, Drive common. If a TTL level “0” is not measured, replace Modulator Logic Board A1.</p> |

| Symptom 3 | DIAGNOSTIC PROCEDURE |
|--|--|
| Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated. | <p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse F5 for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assembly 1REC and Bus Capacitors 2C & 3C as specified in STEPS 1, 2 & 3, symptom 1.</p> <p>STEP 2 – Check for an inoperative K1 Contactor. Measure contactor coil supply voltage at Power Distribution Board A2. There should be +9 to +15V DC between pins 7 & 10 at molex connector J203. There should also be +9 to +15V DC between points 3 & 4 at the contactor. If 9 to 15 volts is measured and K1 is not picked-up, the contactor may be inoperative. If inoperative, replace the Power Distribution Board.</p> <p>STEP 3 – Check pin 10 at molex connector J203 with respect to pin 8, Drive common. If a TTL level "0" is not measured, replace Modulator Logic Board A1.</p> |

| Symptom 4 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OVERLOAD fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated OVERLOAD LED indicates that the Drive has tripped off due to a nominal 110% overload condition which has exceeded the (60) second time period.</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>During acceleration or start-up (breakaway), it is normal for the Overload LED to illuminate momentarily. This merely indicates that a momentary overload current of 110% has been sensed and that the Overload circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the Overload LED is constantly activated during startup (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p> |

| Symptom 5 | DIAGNOSTIC PROCEDURE |
|--|--|
| Motor does not return to full set speed after stalling. Red OVERLOAD fault LED is illuminated. | <p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT: <i>If a 110% continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the Overload LED on the Diagnostic Display Panel.</i></p> </div> |
| Symptom 6 | DIAGNOSTIC PROCEDURE |
| Red OVERLOAD Fault LED is illuminated during DECEL or at (0) Hz. | <p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p> |
| Symptom 7 | DIAGNOSTIC PROCEDURE |
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than:</p> <ul style="list-style-type: none"> ● 414V AC at the 460V AC Tap on Transformer 1T ● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power) ● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse F4 for an open condition.</p> <p>STEP 2 – Check the input voltage to Transformer 1T by measuring the voltage between connectors E11 & E12 on Power Distribution Board A2. If proper voltage is present, replace Modulator Logic Board A1.</p> |

| Symptom 8 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated. | <p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none"> ● Excessively High Input Voltage ● DC Boost Set too High ● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.</p> |

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A , PROT. B , or PROT. C fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated A, B or C phase protection LED indicates:</p> <ul style="list-style-type: none"> ● An output overcurrent condition greater than 180% due to either: <ol style="list-style-type: none"> 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor). 2) An output overcurrent condition greater than 180% due to an output phase-to-ground short. <p>In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block TB2. Reapply power to the Drive and give the Drive a START command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.</p> <p>A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.</p> <p>A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.</p> |

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|---|---|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <ul style="list-style-type: none"> ● Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate. <p>Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied the motor can saturate, resulting in a peak current in excess of 180% causing a phase protect trip. Decrease the DC BOOST, the DECEL RATE or both. Refer to section 5.3.3, DC Boost Adjustment, ACCEL/DECEL Rate Adjustment for additional information.</p> ● Excessive DC boost causing a phase protection trip during acceleration. <p>Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.</p> <p>If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> <p>Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.</p> <ul style="list-style-type: none"> ● A shorted output transistor in one of the Power Switching Modules. <p>Phase "A" ... 1Q Phase "B" ... 2Q Phase "C" ... 3Q</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Driver Board. <p>Phase "A" ... Section A of the Driver Board Phase "B" ... Section B of the Driver Board Phase "C" ... Section C of the Driver Board</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be. <p>Phase "A" ... Section A of the Driver Board Phase "B" ... Section B of the Driver Board Phase "C" ... Section C of the Driver Board</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform. <p>Perform the following four steps to isolate and correct the problem.</p> |

Symptom 9

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. **DS1**, the bus charged neon light on Power Distribution Board A2, should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage between connectors **E17 (+ BUS)** and **E13 (- BUS)** on Power Distribution Board A2. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

Connections Listed in Step 2 are shown on pages A-6 & A-7

STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Unplug connectors **E5, E6, E7 & E13** at the Power Distribution Board.

Unplug the molex connector for the indicated phase at the Driver Board (**J302A, B or C**).

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of both upper and lower power switching transistors at molex connector **J302A, B or C** as follows.

| <u>OHMMETER</u> | | <u>READING</u> |
|-------------------------|--------------------------|-----------------|
| <u>+ LEAD</u> | <u>- LEAD</u> | |
| J302, pin 1 (c1) | J302, pin 6 (E1) | INFINITE |
| J302, pin 6 (c2) | J302, pin 13 (E2) | INFINITE |

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of both upper and lower power switching transistors at molex connector **J302A, B or C** as follows.

| <u>OHMMETER</u> | | <u>READING</u> |
|-------------------------|--------------------------|-----------------|
| <u>+ LEAD</u> | <u>- LEAD</u> | |
| J302, pin 1 (c1) | J302, pin 5 (B1) | INFINITE |
| J302, pin 6 (c2) | J302, pin 12 (B2) | INFINITE |

- If a collector to base short is found in either the upper or lower power switching transistor, replace the module.
- If either transistor has a collector to base short, replace the module and the Driver Board.

IMPORTANT: When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.


STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to **MANUAL** control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, perform **STEP 5** on the following page.

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|--|---|
| (continued) Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A , PROT. B , or PROT. C fault LED is illuminated. | <p>STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed check operation in the auto or normal operating mode. If the Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 5 – Check for proper operation of the current sensing circuits on the Modulator Logic Board and the Driver Board for the indicated phase.</p> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The OVERLOAD LED on the Modulator Logic Board should light when the current reaches a nominal value of 110%. If the OVERLOAD LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <p>Pin 5 – ØA Driver Signal Pin 16 – ØB Driver Signal Pin 27 – ØC Driver Signal</p> <p>If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.</p> <p>If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p> |

| Symptom 10 | DIAGNOSTIC PROCEDURE |
|--|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red DRIVE OVER TEMP fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> <p>An illuminated DRIVE OVER TEMPERATURE LED indicates that the Drive has tripped off due to an over temperature condition. Allow Drive to cool down for approximately (15) minutes before restarting. After restarting, if over temperature condition occurs again, check for the following conditions.</p> <ul style="list-style-type: none"> ● Ambient Temperature that Exceeds the Drive Rating. Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3. ● Heat Flow Obstruction within the Heat Sink Assembly. Visually inspect for unobstructed spacing between fins. Clean if necessary. ● Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time. Using an AC clamp on ammeter, measure the motor current over an extended period of time. <div> <p>IMPORTANT : <i>Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.</i></p> </div> <ul style="list-style-type: none"> ● Malfunctioning Temperature Sensor 1TAS. If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS. <div> <p>IMPORTANT : <i>When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.</i></p> </div> </div> |
| Symptom 11 | DIAGNOSTIC PROCEDURE |
| Bus voltage does not discharge within (60) seconds when input power is removed. Neon light DS1 on Power Distribution Board A2 is illuminated. | <p>After input power is removed the bus voltage should discharge to 42V DC in approximately (60) seconds. If the discharge cycle is not taking place, check to see if resistor 2R or 3R has opened.</p> <p>If neither resistor is open, check for open wiring between the resistors and Bus Capacitors 2C & 3C. If all wiring is correct, replace Power Distribution Board A2.</p> <p>If either resistor is open, replace and reapply input power.</p> <div> <p>IMPORTANT : <i>When replacing resistor 2R or 3R, clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the resistor. Torque mounting screws to 2.6-3.0 in-lbs Max.</i></p> </div> <p>Check for proper bus discharge cycle. Measure the DC voltage between connectors E17 (+ BUS) and E13 (- BUS) on Power Distribution Board A2. After approximately (60) seconds the voltage should be below 42 volts. If discharge cycle is still not taking place and/or either resistor opens again, replace Power Distribution Board A2.</p> |

Bulletin 1335 22, 28 & 36 Amp Troubleshooting

22, 28 & 36 Amp Diagnostic LED Display



22, 28 & 36 Amp Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix B** on pages **B-3** through **B-7**.

All voltage values & polarities referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix J** or the Modulator Logic Board Interconnection Diagram in **Appendix M**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the **STOP** pushbutton has been depressed.

If neon light **DS1** on Bus Indicator Board A41 is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (60) seconds, and ensure that DS1 is not lit before servicing.**



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the **START** Pushbutton Always Ensure:

That the **Speed Pot** or speed reference is set to **MINIMUM**.

That the **AUTO/OFF/MAN Switch** (if present), is in the proper position.

That the **DRIVE/OFF/BYPASS Switch** (if present), is in the proper position.

That the motor is uncoupled from its mechanical load.

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

Symptom 1

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON LED** is not illuminated.

Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.

If any voltage is not present, check the AC line source for an open or missing phase.

If voltage is present, measure voltage across input line fuses **1FU**, **2FU**, and **3FU**. Measure voltage across input primary fuse **4FU** at transformer **1T**. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete **STEPS 1 – 4**.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. The Bus Indicator neon light on Bus Indicator Board **A41** should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

STEP 2 – For 22 & 28 Amp Drives, with an ohmmeter set on the x1 scale, check Rectifier Assembly **1 REC** as follows:

| OHMMETER | | READING |
|-----------------------------|-----------------------------|----------|
| + LEAD | – LEAD | |
| GREEN (1 REC +) | ORANGE (1 REC - AC1) | Infinite |
| GREEN (1 REC +) | GRAY (1 REC - AC2) | Infinite |
| GREEN (1 REC +) | YELLOW (1 REC - AC3) | Infinite |
| ORANGE (1 REC - AC1) | WHITE (1 REC –) | Infinite |
| GRAY (1 REC - AC2) | WHITE (1 REC –) | Infinite |
| YELLOW (1 REC - AC3) | WHITE (1 REC –) | Infinite |

If any of the above readings are not as shown, replace Rectifier Assembly **1 REC**.

STEP 3 – For 36 Amp Drives, with an ohmmeter set on the x1 scale, check Rectifier Assembly **1 REC**, **2 REC**, **3 REC** as follows:

| OHMMETER | | READING |
|-----------------------------|-----------------------------|----------|
| + LEAD | – LEAD | |
| BLACK (1 REC +) | ORANGE (1 REC - AC1) | Infinite |
| BLACK (1 REC +) | YELLOW (2 REC - AC2) | Infinite |
| BLACK (1 REC +) | GREEN (3 REC - AC3) | Infinite |
| ORANGE (1 REC - AC1) | WHITE (1 REC –) | Infinite |
| YELLOW (2 REC - AC2) | WHITE (1 REC –) | Infinite |
| GREEN (3 REC - AC3) | WHITE (1 REC –) | Infinite |

If any of the above readings are not as shown, replace Rectifier Assembly **1 REC**, **2 REC**, **3 REC**.

| Symptom 1 | DIAGNOSTIC PROCEDURE |
|--|--|
| (continued) Drive does not start. Amber POWER ON LED is not illuminated. | <div>IMPORTANT : <i>When replacing the Rectifier Assembly clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.</i></div> STEP 4 – With the ohmmeter set on the x100 scale, check Bus Capacitors 2C1 , 3C1 , 2C2 , & 3C2 for a shorted condition as follows. Remove the capacitor support block and (+) POSITIVE bus bars. Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (–) NEGATIVE lead of the ohmmeter to the (–) NEGATIVE capacitor bus bar. The ohmmeter should immediately read low, then slowly increase to approximately 20k Ω . A sustained low reading indicates a shorted capacitor that requires replacement. After completing STEPS 1 – 4 , replace blown fuses and reapply input power. |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|---|---|
| <p>Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated.</p> | <p>Check for line out condition at fuse 3FU by measuring the AC line voltage from L3 to either L1 or L2.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across 3FU. A voltage across 3FU indicates that it is open and must be replaced. Before replacing 3FU, perform STEPS 1 – 4 in Symptom 1, then the following eleven steps.</p> <p>STEP 1 – Check precharge circuit fuse 5FU for an open condition.</p> <p>STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.</p> <p>STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment R25 or the minimum speed pot adjustment R26 may be ineffective. Refer to section 5.3.1, Minimum and Maximum Speed Adjust.</p> <ul style="list-style-type: none"> • If option N, N4 or G4 is installed, ensure that: The AUTO/MAN switch on the card is set to the MAN mode. A 1kΩ, 2W, linear taper speed pot has been properly connected to Terminal Block 1TB between terminals 14, 15 & 16. • If option T16, T17 or T18 is installed, check for continuity across the Motor Overload Relay contact circuit, terminals 10 & 11 at Terminal Block 1TB. <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 4 – Check for an open speed pot at Terminal Block 1TB. Measure the voltage at Terminal Block 1TB between terminals 14 & 16. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals 14, 15 & 16. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals 15 & 16 should vary from 0 to 3.2V DC. Replace or correct as required.</p> <p>STEP 5 – Check the voltage between terminals 9 & 11 at Terminal Block 1TB.</p> <ul style="list-style-type: none"> • If standard START/STOP configuration is used, there should be 90V AC between terminals 9 & 11. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to 1TB. • If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6. • If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.5. |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|--|--|
| (continued) | |
| Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated. | <p>STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T.</p> <p>The following voltages should be present at Power Supply Board A6.</p> <p>molex connector J602 between pins 4 & 1 14V AC molex connector J602 between pins 2 & 1 14V AC molex connector J602 between pins 5 & 6 15V AC</p> <p>The following voltage should be present at terminal block 1TB.</p> <p>between terminals 1 & 11 90V AC</p> <p>If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.</p> <p>STEP 7 – Go to Logic Power Supply Board A6 and measure all output voltages. The following voltages should be present at molex connector J601 with respect to Drive common, J601 Pin 1. If any one voltage is absent, replace A6.</p> <p>J601, pin 2 14V AC J601, pin 3 + 17V DC J601, pin 5 + 9 to + 15V DC (nominal) J601, pin 6 + 9 to + 15V DC (nominal) J601, pin 9 -17V DC</p> <p>STEP 8 – Measure the output voltage across the secondary circuit of Transformer 2T, pins 5 & 6. If 17V AC is absent, replace 2T.</p> <p>STEP 9 – If 2T checks out, Contactor Interface Board A9 may be inoperative. The following voltages should be present with respect to Drive common, J901 Pin 1.</p> <p>J901, pin 4 + 24V DC J901, pin 6 0V DC (nominal) J901, pin 7 0V DC (nominal) J901, pin 8 + 11V DC</p> <p>STEP 10 – If Transformer 2T and Contactor Interface Board A9 check out, measure the control voltage at contactor 1CON. There should be + 24V DC between points C1 & C2 at the contactor. If + 24V DC is measured and 1CON is not picked-up, the contactor may be inoperative. Replace if required.</p> <p>If the problem cannot be found after completing STEPS 1 – 10, replace Modulator Logic Board A1.</p> |

| Symptom 3 | DIAGNOSTIC PROCEDURE | | | | | | |
|--|--|---|---------------------------|---------------------------------------|-----------------------------|--|-----------------------------|
| Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated. | <p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse 5FU for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assemblies and Bus Capacitors as specified in STEPS 1 – 4, symptom 1.</p> <p>STEP 2 – Check Precharge Contactor Interface Board A9. The following voltages should be present at connector J901 on the Contactor Interface Board. Replace if required.</p> <table> <tr> <td>Transformer 2T secondary voltage</td><td>17V AC between pins 2 & 3</td></tr> <tr> <td>Contactor 1CON control voltage</td><td>+ 24V DC between pins 4 & 6</td></tr> <tr> <td></td><td>+ 11V DC between pins 7 & 8</td></tr> </table> <p>If the problem cannot be found after completing STEPS 1 & 2, replace Modulator Logic Board A1.</p> | Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | + 11V DC between pins 7 & 8 |
| Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | | | | | | |
| Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | | | | | |
| | + 11V DC between pins 7 & 8 | | | | | | |

| Symptom 4 | DIAGNOSTIC PROCEDURE |
|---|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OVERLOAD fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated OVERLOAD LED indicates that the Drive has tripped off due to a nominal 110% overload condition which has exceeded the (60) second time period.</p> <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>During acceleration or startup (breakaway), it is normal for the Overload LED to illuminate momentarily. This merely indicates that a momentary overload current of 110% has been sensed and that the Overload circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the Overload LED is constantly activated during startup (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p> |

| Symptom 5 | DIAGNOSTIC PROCEDURE |
|--|--|
| Motor does not return to full set speed after stalling. Red OVERLOAD fault LED is illuminated. | <p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> <div> <p>IMPORTANT: <i>If a 110 % continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the Overload LED on the Diagnostic Display Panel.</i></p> </div> |
| Symptom 6 | DIAGNOSTIC PROCEDURE |
| Red OVERLOAD fault LED is illuminated during DECEL or at (0) Hz. | <p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p> |
| Symptom 7 | DIAGNOSTIC PROCEDURE |
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than 414V AC at the 460V AC Tap on Transformer 1T</p> <ul style="list-style-type: none"> ● 414V AC at the 460V AC Tap on Transformer 1T ● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power) ● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse 4FU for an open condition.</p> <p>STEP 2 – Measure the input voltage to Transformer 1T. If proper voltage is present, replace Modulator Logic Board A1.</p> |

| Symptom 8 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated. | <p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none"> ● Excessively High Input Voltage ● DC Boost Set too High ● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.</p> |

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A , PROT. B , or PROT. C fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated A, B or C phase protection LED indicates:</p> <ul style="list-style-type: none"> ● An output overcurrent condition greater than 180% due to either: <ol style="list-style-type: none"> 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor). 2) An output overcurrent condition greater than 180% due to an output phase-to-ground short. <p>In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block 2TB. Reapply power to the Drive and give the Drive a START command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.</p> <p>A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.</p> <p>A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.</p> |

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|---|---|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <ul style="list-style-type: none"> ● Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate. Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied, the motor can saturate, resulting in a peak current in excess of 180% causing a phase protect trip. Decrease the DC BOOST, the DECEL RATE or both. Refer to section 5.3.3, DC Boost Adjustment, ACCEL/DECEL Rate Adjustment for additional information. ● Excessive DC boost causing a phase protection trip during acceleration. Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings. If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance. <p>Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.</p> <ul style="list-style-type: none"> ● A shorted output transistor in one of the Power Switching Modules. Phase "A" ... 1Q1, 1Q2 Phase "B" ... 2Q1, 2Q2 Phase "C" ... 3Q1, 3Q2 Perform the following four steps to isolate and correct the problem. ● A malfunctioning Driver Board. Phase "A" ... A3A Phase "B" ... A3B Phase "C" ... A3C Perform the following four steps to isolate and correct the problem. ● A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be. Phase "A" ... A3A Phase "B" ... A3B Phase "C" ... A3C Perform the following four steps to isolate and correct the problem. ● A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform. Perform the following four steps to isolate and correct the problem. |

Symptom 9


(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.

DIAGNOSTIC PROCEDURE

STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. DS1, the bus charged neon light on Bus Indicator Board A41 should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage at connector J402 between pins 5 (+ BUS) and 1 (– BUS) on Voltage Sensing Board A4. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

Connections Listed in Step 2 are shown in detail on pages B-4 & B-6



STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Disconnect the (+) BUS lead at C1 for the indicated phase at the Power Switching Module.

Disconnect the (–) BUS lead at E2 at the Power Switching Module.

Unplug the molex connector for the indicated phase at the Driver Board (J302A, B or C).

Disconnect one end of the jumper bar that is connected between terminals E1, C2 on the two Power Switching Modules and the output phase lead to terminal 2TB. This will enable you to check all four transistors independently.

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of both upper and lower power switching transistors for each module as follows.

| OHMMETER | | READING |
|----------|--------|----------|
| + LEAD | – LEAD | |
| C1 | E1 | INFINITE |
| C2 | E2 | INFINITE |

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of both upper and lower power switching transistors for each module as follows.

| OHMMETER | | READING |
|----------|--------|----------|
| + LEAD | – LEAD | |
| C1 | B1 | INFINITE |
| C2 | B2 | INFINITE |

- If a collector to emitter short is found in either the upper or lower power switching transistor, replace the module.
- If either transistor has a collector to base short, replace the module and the Driver Board.

IMPORTANT: When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <p>STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to MANUAL control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed, check operation in the auto or normal operating mode. If the Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 5 – Check for proper operation of the current sensing circuits on the Modulator Logic Board and the Driver Board for the indicated phase.</p> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The OVERLOAD LED on the Modulator Logic Board should light when the current reaches a nominal value of 110%. If the OVERLOAD LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <p style="text-align: center;">Pin 5 – ØA Driver Signal Pin 16 – ØB Driver Signal Pin 27 – ØC Driver Signal</p> <p>If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.</p> <p>If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p> |

| Symptom 10 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red DRIVE OVER TEMP. fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated DRIVE OVER TEMPERATURE LED indicates that the Drive has tripped off due to an over temperature condition. Allow Drive to cool down for approximately (15) minutes before restarting. After restarting, if over temperature condition occurs again, check for the following conditions.</p> <ul style="list-style-type: none"> ● Ambient Temperature that Exceeds the Drive Rating. Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3. ● Heat Flow Obstruction within the Heat Sink Assembly. Visually inspect for unobstructed spacing between fins. Clean if necessary. ● Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time. Using an AC clamp on ammeter, measure the motor current over an extended period of time. <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.</i></p> </div> <ul style="list-style-type: none"> ● Malfunctioning Temperature Sensor 1TAS. If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS. <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.</i></p> </div> |

| Symptom 11 | DIAGNOSTIC PROCEDURE |
|---|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OUTPUT GND fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated OUTPUT GROUND LED indicates that the Drive circuitry has shorted to ground or there is a malfunctioning Output Ground Sensor Board A8.</p> <p>Remove input power to the Drive and disconnect the motor from the Drive. Reapply input power and start the Drive.</p> <p>If the Drive does not trip, check the motor for a grounded phase condition. Replace or repair the motor if required.</p> <p>If the Drive trips with the motor disconnected, check wire insulation and terminal connections on the Drive chassis for shorts to ground. If the problem still cannot be located, replace Output Ground Sensor Board A8.</p> |

| Symptom 12 | DIAGNOSTIC PROCEDURE |
|--|--|
| Bus voltage does not discharge within (60) seconds when input power is removed. Neon light DS1 on Bus Indicator Board A41 is illuminated. | <p>After input power is removed the bus voltage should discharge to 42V DC in approximately (60) seconds. If the discharge cycle is not taking place, check to see if resistor 2R or 3R has opened.</p> <p>If neither resistor is open, check for open wiring between the resistors and Bus Capacitors 2C & 3C.</p> <p>If either resistor is open, replace and reapply input power.</p> <div><p>IMPORTANT : <i>When replacing resistor 2R or 3R, clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the resistor. Torque mounting screws to 2.6-3.0 in-lbs max.</i></p></div> <p>Check for proper bus discharge cycle. Measure the DC voltage at Voltage Sensing Board A4, connector J402, between pins 5 (+ BUS) and 1 (– BUS). After approximately (60) seconds the voltage should be below 42 volts. If discharge cycle is still not taking place and/or either resistor opens again, replace Bus Indicator Board A41.</p> |

Bulletin 1335 56 & 69 Amp Troubleshooting

56 & 69 Amp Diagnostic LED Display

Power ON – Indicates input power is connected when illuminated.

Overload Protection – When constantly illuminated indicates an over current condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.

Under Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.

Over Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to the bus voltage exceeding 760V DC.

"A" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "A" Phase Output Transistor
- Section "A" of the Driver Board is Malfunctioning

"B" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "B" Phase Output Transistor
- Section "B" of the Driver Board is Malfunctioning

"C" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "C" Phase Output Transistor
- Section "C" of the Driver Board is Malfunctioning

Drive Over Temperature Protection Trip – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.

Output Ground Fault Protection Trip Indication – When illuminated indicates that the Drive circuitry has shorted to GROUND.

DS1 – Located on Bus Indicator Board A41 – When illuminated indicates that the bus potential is in excess of 42V DC.

Symptom
1, 2 & 3

Symptom
4, 5, 6, & 7

Symptom
8

Symptom
9

Symptom
10



Symptom
10

Symptom
10

Symptom
11


Symptom
12

Symptom
13



56 & 69 Amp Driver Board LED Indication

There are no adjustment settings for Bulletin 1335 56 & 69 Amp Driver Boards. Each Driver Board does however provide fuse status indication. Two LEDs, CR18 and CR19, indicate the status of fuses F1 and F2 on each Driver Board respectively. An illuminated LED means that its associated fuse has opened as described in **Symptom 10** in the following troubleshooting procedures.



56 & 69 Amp Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix C** on pages **C-3** through **C-5**.

All **voltage values & polarities** referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix K** or the Modulator Logic Board Interconnection Diagram in **Appendix M**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the STOP pushbutton has been depressed.

If neon light **DS1** on Bus Indicator Board A41 is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (60) seconds, and ensure that DS1 is not lit before servicing.**



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the START Pushbutton Always Ensure:

That the **Speed Pot** or speed reference is set to **MINIMUM**.

That the **AUTO/OFF/MAN Switch** (if present), is in the proper position.

That the **DRIVE/OFF/BYPASS Switch** (if present), is in the proper position.

That the motor is uncoupled from its mechanical load.

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

| Symptom 1 | DIAGNOSTIC PROCEDURE | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|----------|--|---------|--------|--------|--|------------------------|-----------------------------|----------|------------------------|-----------------------------|----------|------------------------|----------------------------|----------|-----------------------------|------------------------|----------|-----------------------------|------------------------|----------|----------------------------|------------------------|----------|
| Drive does not start. Amber POWER ON LED is not illuminated. | <p>Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across input line fuses 1FU, 2FU, and 3FU. Measure voltage across input primary fuse 4FU at transformer 1T. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete STEPS 1, 2 and 3.</p> <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. The Bus Indicator neon light on Bus Indicator Board A41 should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> <p>STEP 2 – With an ohmmeter set on the x1 scale, check Rectifier Assembly 1 REC, 2 REC, 3 REC as follows:</p> <table><tr><th colspan="2">OHMMETER</th><th>READING</th></tr><tr><th>+ LEAD</th><th>– LEAD</th><th></th></tr><tr><td>BLACK (1 REC +)</td><td>ORANGE (1 REC - AC1)</td><td>Infinite</td></tr><tr><td>BLACK (1 REC +)</td><td>YELLOW (2 REC - AC2)</td><td>Infinite</td></tr><tr><td>BLACK (1 REC +)</td><td>GREEN (3 REC - AC3)</td><td>Infinite</td></tr><tr><td>ORANGE (1 REC - AC1)</td><td>BLACK (1 REC -)</td><td>Infinite</td></tr><tr><td>YELLOW (2 REC - AC2)</td><td>BLACK (1 REC -)</td><td>Infinite</td></tr><tr><td>GREEN (3 REC - AC3)</td><td>BLACK (1 REC -)</td><td>Infinite</td></tr></table> <p>If any of the above readings are not as shown, replace Rectifier Assembly 1 REC, 2 REC, 3 REC.</p> <div><p>IMPORTANT : <i>When replacing the Rectifier Assembly clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.</i></p></div> <p>STEP 3 – With the ohmmeter set on the x100 scale, check Bus Capacitors for a shorted condition as follows.</p> <p>Remove the capacitor support block and (+) POSITIVE bus bars.</p> <p>Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (–) NEGATIVE lead of the ohmmeter to the (–) NEGATIVE capacitor bus bar.</p> <p>The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.</p> <p>After completing STEPS 1, 2 & 3, replace blown fuses and reapply input power.</p> | OHMMETER | | READING | + LEAD | – LEAD | | BLACK (1 REC +) | ORANGE (1 REC - AC1) | Infinite | BLACK (1 REC +) | YELLOW (2 REC - AC2) | Infinite | BLACK (1 REC +) | GREEN (3 REC - AC3) | Infinite | ORANGE (1 REC - AC1) | BLACK (1 REC -) | Infinite | YELLOW (2 REC - AC2) | BLACK (1 REC -) | Infinite | GREEN (3 REC - AC3) | BLACK (1 REC -) | Infinite |
| OHMMETER | | READING | | | | | | | | | | | | | | | | | | | | | | | |
| + LEAD | – LEAD | | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | ORANGE (1 REC - AC1) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | YELLOW (2 REC - AC2) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | GREEN (3 REC - AC3) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| ORANGE (1 REC - AC1) | BLACK (1 REC -) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| YELLOW (2 REC - AC2) | BLACK (1 REC -) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| GREEN (3 REC - AC3) | BLACK (1 REC -) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated.</p> | <p>Check for line out condition at fuse 3FU by measuring the AC line voltage from L3 to either L1 or L2.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across 3FU. A voltage across 3FU indicates that it is open and must be replaced. Before replacing 3FU, perform STEPS 1, 2 & 3 in Symptom 1, then the following eleven steps.</p> <p>STEP 1 – Check precharge circuit fuse 5FU for an open condition.</p> <p>STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.</p> <p>STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment R25, or the minimum speed pot adjustment R26, may be ineffective. Refer to section 5.3.1, Minimum and Maximum Speed Adjust.</p> <ul style="list-style-type: none"> ● If option N, N4, or G4 is installed, ensure that: <ul style="list-style-type: none"> The AUTO/MAN switch on the card is set to the MAN mode. A 1kΩ, 2W, linear taper speed pot has been properly connected to Terminal Block 1TB between terminals 14, 15 & 16. ● If option T19 or T20 is installed, check for continuity across the Motor Overload Relay contact circuit, terminals 10 & 11 at Terminal Block 1TB. <p>STEP 4 – Check for an open speed pot at Terminal Block 1TB. Measure the voltage at Terminal Block 1TB between terminals 14 & 16. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals 14, 15 & 16. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals 15 & 16 should vary from 0 to 3.2V DC. Replace or correct as required.</p> <p>STEP 5 – Check the voltage between terminals 9 & 11 at Terminal Block 1TB.</p> <ul style="list-style-type: none"> ● If standard START/STOP configuration is used, there should be 90V AC between terminals 9 & 11. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to 1TB. <ul style="list-style-type: none"> – For a Standard Drive Without Factory Installed Options – ● If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6. ● If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.5. |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|--|---|
| (continued) | |
| Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated. | <p>STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T.</p> <p>The following voltages should be present at Power Supply Board A6.</p> <p>molex connector J602 between pins 4 & 1 14V AC molex connector J602 between pins 2 & 1 14V AC molex connector J602 between pins 5 & 6 15V AC</p> <p>The following voltage should be present at terminal block 1TB.</p> <p>between terminals 1 & 11 90V AC</p> <p>If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.</p> <p>STEP 7 – Go to Logic Power Supply Board A6 and measure all output voltages. The following voltages should be present at molex connector J601 with respect to Drive common, J601 Pin 1. If any one voltage is absent, replace A6.</p> <p>J601, pin 2 14V AC J601, pin 3 + 17V DC J601, pin 5 + 9 to + 15V DC (nominal) J601, pin 6 + 9 to + 15V DC (nominal) J601, pin 9 -17V DC</p> <p>STEP 8 – Measure the output voltage across the secondary circuit of Transformer 2T, pins 5 & 6. If 17V AC is absent, replace 2T.</p> <p>STEP 9 – If 2T checks out, Contactor Interface Board A9 may be inoperative. The following voltages should be present with respect to Drive common, J901 Pin 1.</p> <p>J901, pin 4 + 24V DC J901, pin 6 0V DC (nominal) J901, pin 7 0V DC (nominal) J901, pin 8 + 11V DC</p> <p>STEP 10 – If Transformer 2T and Contactor Interface Board A9 check out, measure the control voltage at contactor 1CON. There should be + 24V DC between points C1 & C2 at the contactor. If + 24V DC is measured and 1CON is not picked-up, the contactor may be inoperative. Replace if required.</p> <p>If the problem cannot be found after completing STEPS 1 – 10, replace Modulator Logic Board A1.</p> |

| Symptom 3 | DIAGNOSTIC PROCEDURE | | | | | | |
|---|--|---|--------------------------------------|---------------------------------------|--|--|--|
| Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated. | <p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse 5FU for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assemblies and Bus Capacitors as specified in STEPS 1, 2 & 3, Symptom 1.</p> <p>STEP 2 – Check Precharge Contactor Interface Board A9. The following voltages should be present at connector J901 on the Contactor Interface Board. Replace if required.</p> <table> <tr> <td>Transformer 2T secondary voltage</td><td>17V AC between pins 2 & 3</td></tr> <tr> <td>Contactor 1CON control voltage</td><td>+ 24V DC between pins 4 & 6</td></tr> <tr> <td></td><td>+ 11V DC between pins 7 & 8</td></tr> </table> <p>If the problem cannot be found after completing STEPS 1 & 2, replace Modulator Logic Board A1.</p> | Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | + 11V DC between pins 7 & 8 |
| Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | | | | | | |
| Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | | | | | |
| | + 11V DC between pins 7 & 8 | | | | | | |

| Symptom 4 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive trips just after input line power is applied before START command is given. Red OVERLOAD fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated OVERLOAD LED indicates that there may be a loss of input power to the Driver Boards.</p> <p>Check the power supply at all three Driver Boards. Approximately 16V AC should be measured between pins 1 & 2 at each J301 connector. If not, check fuse F1 on Driver Power Supply Board A10. Replace if required and check voltage again.</p> <p>If voltage is not present, replace Driver Power Supply Board A10.</p> <p>If voltage is present, perform the diagnostic procedure in Symptom 5.</p> |

| Symptom 5 | DIAGNOSTIC PROCEDURE |
|---|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OVERLOAD fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> <p>An illuminated OVERLOAD LED indicates that the Drive has tripped off due to a nominal 110% overload condition which has exceeded the (60) second time period.</p> <div> <p>IMPORTANT : <i>During acceleration or startup (breakaway), it is normal for the Overload LED to illuminate momentarily. This merely indicates that a momentary overload current of 110% has been sensed and that the Overload circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the Overload LED is constantly activated during startup (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p> </div> |
| Symptom 6 | DIAGNOSTIC PROCEDURE |
| Motor does not return to full set speed after stalling. Red OVERLOAD fault LED is illuminated. | <div> <p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> <div> <p>IMPORTANT: <i>If a continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the Overload LED on the Diagnostic Display Panel.</i></p> </div> </div> |
| Symptom 7 | DIAGNOSTIC PROCEDURE |
| Red OVERLOAD fault LED is illuminated during DECEL or at (0) Hz. | <div> <p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p> </div> |

| Symptom 8 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated.</p> | <div data-bbox="446 336 1469 415" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than 414V AC at the 460V AC Tap on Transformer 1T</p> <ul style="list-style-type: none"> ● 414V AC at the 460V AC Tap on Transformer 1T ● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power) ● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse 4FU for an open condition.</p> <p>STEP 2 – Measure the input voltage to Transformer 1T. If proper voltage is present, replace Modulator Logic Board A1.</p> |

| Symptom 9 | DIAGNOSTIC PROCEDURE |
|--|---|
| <p>Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated.</p> | <p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none"> ● Excessively High Input Voltage ● DC Boost Set too High ● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.</p> |

Symptom 10

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

DIAGNOSTIC PROCEDURE

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **A**, **B** or **C** phase protection LED indicates:

- **An output overcurrent condition greater than 180% due to either:**

- 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor).
- 2) An output overcurrent condition greater than 180% due to an output phase-to-ground short.

In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block **2TB**. Reapply power to the Drive and give the Drive a **START** command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.

A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.

A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.

- **Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate.**

Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied, the motor can saturate, resulting in a peak current in excess of 180% causing a phase protect trip. Decrease the **DC BOOST**, the **DECEL RATE** or both. Refer to section 5.3.3, **DC Boost Adjustment, ACCEL/DECEL Rate Adjustment** for additional information.

- **Excessive DC boost causing a phase protection trip during acceleration.**

Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.

If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.

Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.

| Symptom 10 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <ul style="list-style-type: none"> ● A shorted output transistor in one of the Power Switching Modules. <p>Phase "A" ... 1Q1, 1Q2</p> <p>Phase "B" ... 2Q1, 2Q2</p> <p>Phase "C" ... 3Q1, 3Q2</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Driver Board. <p>Phase "A" ... A3A</p> <p>Phase "B" ... A3B</p> <p>Phase "C" ... A3C</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be. <p>Phase "A" ... A3A</p> <p>Phase "B" ... A3B</p> <p>Phase "C" ... A3C</p> <p>Perform the following four steps to isolate and correct the problem.</p> ● A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform. <p>Perform the following four steps to isolate and correct the problem.</p> <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. DS1, the bus charged neon light on Bus Indicator Board A41 should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage at connector J402 between pins 5 (+ BUS) and 1 (– BUS) on Voltage Sensing Board A4. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> |


Symptom 10

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

DIAGNOSTIC PROCEDURE

Connections Listed in Step 2 are shown in detail on page C-4



STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

 Disconnect all leads to **C1** at the Power Switching Module.

 Disconnect all leads to **E2** at the Power Switching Module.

 Unplug the molex connector for the indicated phase at the Driver Board (**J303A**, **B**, or **C**).

 Disconnect one end of the jumper bar that is connected between terminals **E1,C2** on the two power switching modules. This will enable you to check each transistor independently.

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of each module as follows.

| OHMMETER | | READING |
|----------|--------|----------|
| + LEAD | – LEAD | |
| C1 | E1 | INFINITE |
| C2 | E2 | INFINITE |

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of each module as follows.

| OHMMETER | | READING |
|----------|--------|----------|
| + LEAD | – LEAD | |
| C1 | B1 | INFINITE |
| C2 | B2 | INFINITE |

If a short is found, replace the module and check the following.

IMPORTANT : When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

- DC Bus Fuse **8FU** for an open condition.
- Fuse **F1** on Driver Power Supply Board **A10**. If fuse **F1** is open, replace the board.
- Fuses **F1** & **F2** on the Driver Board for the indicated phase. If either fuse is open or it was noted that with input power applied either LED on the Driver Board was illuminated, replace the Driver Board. An illuminated LED indicates an open fuse which usually indicates failed components on the Driver Board.

| Symptom 10 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <p>STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to MANUAL control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed, check operation in the auto or normal operating mode. If Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 5 – Check for proper operation of the current sensing circuits on the Modulator Logic Board and the Driver Board for the indicated phase.</p> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The OVERLOAD LED on the Modulator Logic Board should light when the current reaches a nominal value of 110%. If the OVERLOAD LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <p style="text-align: center;">Pin 5 – ØA Driver Signal Pin 16 – ØB Driver Signal Pin 27 – ØC Driver Signal</p> <p>If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.</p> <p>If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p> |

| Symptom 11 | DIAGNOSTIC PROCEDURE |
|--|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red DRIVE OVER TEMP fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> <p>An illuminated DRIVE OVER TEMPERATURE LED indicates that the Drive has tripped off due to an over temperature condition. Allow the Drive to cool down for approximately (15) minutes before restarting. After restarting, if an over temperature condition occurs again, check for the following conditions.</p> <ul style="list-style-type: none"> ● Ambient Temperature that Exceeds the Drive Rating. Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3. ● Heat Flow Obstruction within the Heat Sink Assembly. Visually inspect for unobstructed spacing between fins. Clean if necessary. ● Drive Fan Obstruction, Open Fan Fuse 7FU or Malfunctioning Fan. Check and replace as required. ● Open Winding or Connection to Transformer 3T. Check for 115V AC between terminals 5 & 6 on transformer 3T. Replace if required. ● Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time. Using an AC clamp on ammeter, measure the motor current over an extended period of time. <div> <p>IMPORTANT : <i>Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.</i></p> </div> <ul style="list-style-type: none"> ● Malfunctioning Temperature Sensor 1TAS. If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS. <div> <p>IMPORTANT : <i>When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.</i></p> </div> </div> |

| Symptom 12 | DIAGNOSTIC PROCEDURE |
|---|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OUTPUT GND fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> <p>An illuminated OUTPUT GROUND LED indicates that the Drive circuitry has shorted to ground or there is a malfunctioning Output Ground Sensor Board A8.</p> <p>Remove input power to the Drive and disconnect the motor from the Drive. Reapply input power and start the Drive.</p> <p>If the Drive does not trip, check the motor for a grounded phase condition. Replace or repair the motor if required.</p> <p>If the Drive trips with the motor disconnected, check wire insulation and terminal connections on the Drive Chassis for shorts to ground. If the problem still cannot be located, replace Output Ground Sensor Board A8.</p> </div> |

Symptom 13

DIAGNOSTIC PROCEDURE

Bus voltage does not discharge within (60) seconds when input power is removed. Neon light **DS1** on Bus Indicator Board A41 is illuminated. Red **OVERLOAD LED** may or may not be illuminated.

After input power is removed the bus voltage should discharge to 42V DC in approximately (60) seconds if the discharge cycle is taking place.

STEP 1 – If the **OVERLOAD LED** is illuminated, check the power supply at all three Driver Boards. Approximately 16V AC should be measured between pins 1 & 2 at each **J301** connector. If not, check fuse F1 on Driver Power Supply Board A10. Replace if required and check voltage again. If voltage is still not present, replace Driver Power Supply Board A10.

STEP 2 – If the **OVERLOAD LED** is not illuminated, check to see if resistor 2R or 3R has opened.

If neither resistor is open, check for open wiring between the resistors and Bus Capacitors 2C & 3C.

If either resistor is open, replace and reapply input power.

IMPORTANT : When replacing resistor 2R or 3R, clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the resistor. Torque mounting screws to 2.6-3.0 in-lbs max.

Check for proper bus discharge cycle by measuring the DC Bus voltage at Voltage Sensing Board A5, connector **J402**, between pins 5 (+ BUS) and 1 (– BUS). After approximately (60) seconds the voltage should be below 42V DC. If discharge cycle is still not taking place and/or either resistor opens again, replace Voltage Sensing Board A41.

H

Bulletin 1335 77 & 96 Amp Troubleshooting

77 & 96 Amp Diagnostic LED Display

Power ON – Indicates input power is connected when illuminated.

Symptom
1, 2 & 3

Overload Protection – When constantly illuminated indicates an over current condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.

Symptom
4, 5, 6, 7, & 8

Under Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.

Symptom
9

Over Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to the bus voltage exceeding 760V DC.

Symptom
10

"A" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "A" Phase Output Transistor
- Section "A" of the Driver Board is Malfunctioning

Symptom
11

"B" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "B" Phase Output Transistor
- Section "B" of the Driver Board is Malfunctioning

Symptom
11

"C" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 180%
- A Shorted "C" Phase Output Transistor
- Section "C" of the Driver Board is Malfunctioning

Symptom
11

Drive Over Temperature Protection Trip – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.



Symptom
12

Output Ground Fault Protection Trip Indication – When illuminated indicates that the Drive circuitry has shorted to GROUND.

Symptom
13


DS1 – Located on Bus Indicator Board A41 – When illuminated indicates that the bus potential is in excess of 42V DC.

Symptom
14



**77 & 96 Amp
Driver Board LED Indication**

There are no adjustment settings for Bulletin 1335 77 & 96 Amp Driver Boards. Each Driver Board does however provide fuse status indication. Two LEDs, CR18 and CR19, indicate the status of fuses F1 and F2 on each Driver Board respectively. An illuminated LED means that its associated fuse has opened as described in **Symptom 11** in the following troubleshooting procedures.



77 & 96 Amp Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix D** on pages **D-3** through **D-5**.

All **voltage values & polarities** referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix L** or the Modulator Logic Board Interconnection Diagram in **Appendix M**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the STOP pushbutton has been depressed.

If neon light **DS1** on Bus Indicator Board A41 is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (60) seconds, and ensure that DS1 is not lit before servicing.**



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the START Pushbutton Always Ensure:

That the **Speed Pot** or speed reference is set to **MINIMUM**.

That the **AUTO/OFF/MAN Switch** (if present), is in the proper position.

That the **DRIVE/OFF/BYPASS Switch** (if present), is in the proper position.

That the motor is uncoupled from its mechanical load.

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

| Symptom 1 | DIAGNOSTIC PROCEDURE | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|----------|--|---------|--------|--------|--|------------------------|-----------------------------|----------|------------------------|-----------------------------|----------|------------------------|----------------------------|----------|-----------------------------|------------------------|----------|-----------------------------|------------------------|----------|----------------------------|------------------------|----------|
| Drive does not start. Amber POWER ON LED is not illuminated. | <p>Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across input line fuses 1FU, 2FU, and 3FU. Measure voltage across input primary fuse 4FU at transformer 1T. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete STEPS 1, 2 and 3.</p> <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. The Bus Indicator neon light on Bus Indicator Board A41 should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> <p>STEP 2 – With an ohmmeter set on the x1 scale, check Rectifier Assembly 1 REC, 2 REC, 3 REC as follows:</p> <table><tr><th colspan="2">OHMMETER</th><th>READING</th></tr><tr><th>+ LEAD</th><th>– LEAD</th><th></th></tr><tr><td>BLACK (1 REC +)</td><td>ORANGE (1 REC - AC1)</td><td>Infinite</td></tr><tr><td>BLACK (1 REC +)</td><td>YELLOW (2 REC - AC2)</td><td>Infinite</td></tr><tr><td>BLACK (1 REC +)</td><td>GREEN (3 REC - AC3)</td><td>Infinite</td></tr><tr><td>ORANGE (1 REC - AC1)</td><td>BLACK (1 REC –)</td><td>Infinite</td></tr><tr><td>YELLOW (2 REC - AC2)</td><td>BLACK (1 REC –)</td><td>Infinite</td></tr><tr><td>GREEN (3 REC - AC3)</td><td>BLACK (1 REC –)</td><td>Infinite</td></tr></table> <p>If any of the above readings are not as shown, replace Rectifier Assembly 1 REC, 2 REC, 3 REC.</p> <div><p>IMPORTANT : When replacing the Rectifier Assembly clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.</p></div> <p>STEP 3 – With the ohmmeter set on the x100 scale, check Bus Capacitors for a shorted condition as follows.</p> <p>Remove the capacitor support block and (+) POSITIVE bus bars.</p> <p>Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (–) NEGATIVE lead of the ohmmeter to the (–) NEGATIVE capacitor bus bar.</p> <p>The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.</p> <p>After completing STEPS 1, 2 & 3, replace blown fuses and reapply input power.</p> | OHMMETER | | READING | + LEAD | – LEAD | | BLACK (1 REC +) | ORANGE (1 REC - AC1) | Infinite | BLACK (1 REC +) | YELLOW (2 REC - AC2) | Infinite | BLACK (1 REC +) | GREEN (3 REC - AC3) | Infinite | ORANGE (1 REC - AC1) | BLACK (1 REC –) | Infinite | YELLOW (2 REC - AC2) | BLACK (1 REC –) | Infinite | GREEN (3 REC - AC3) | BLACK (1 REC –) | Infinite |
| OHMMETER | | READING | | | | | | | | | | | | | | | | | | | | | | | |
| + LEAD | – LEAD | | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | ORANGE (1 REC - AC1) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | YELLOW (2 REC - AC2) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| BLACK (1 REC +) | GREEN (3 REC - AC3) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| ORANGE (1 REC - AC1) | BLACK (1 REC –) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| YELLOW (2 REC - AC2) | BLACK (1 REC –) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |
| GREEN (3 REC - AC3) | BLACK (1 REC –) | Infinite | | | | | | | | | | | | | | | | | | | | | | | |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated.</p> | <p>Check for line out condition at fuse 3FU by measuring the AC line voltage from L3 to either L1 or L2.</p> <p>If any voltage is not present, check the AC line source for an open or missing phase.</p> <p>If voltage is present, measure voltage across 3FU. A voltage across 3FU indicates that it is open and must be replaced. Before replacing 3FU, perform STEPS 1, 2 & 3 in Symptom 1, then the following eleven steps.</p> <p>STEP 1 – Check precharge circuit fuse 5FU for an open condition.</p> <p>STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.</p> <p>STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment R25, or the minimum speed pot adjustment R26, may be ineffective. Refer to section 5.3.1, Minimum and Maximum Speed Adjust.</p> <ul style="list-style-type: none"> ● If option N, N4, or G4 is installed, ensure that: <ul style="list-style-type: none"> The AUTO/MAN switch on the card is set to the MAN mode. A 1kΩ, 2W, linear taper speed pot has been properly connected to Terminal Block 1TB between terminals 14, 15 & 16. ● If option T21 or T22 is installed, check for continuity across the Motor Overload Relay contact circuit, terminals 10 & 11 at Terminal Block 1TB. <p>STEP 4 – Check for an open speed pot at Terminal Block 1TB. Measure the voltage at Terminal Block 1TB between terminals 14 & 16. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals 14, 15 & 16. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals 15 & 16 should vary from 0 to 3.2V DC. Replace or correct as required.</p> <p>STEP 5 – Check the voltage between terminals 9 & 11 at Terminal Block 1TB.</p> <ul style="list-style-type: none"> ● If standard START/STOP configuration is used, there should be 90V AC between terminals 9 & 11. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to 1TB. <ul style="list-style-type: none"> – For a Standard Drive Without Factory Installed Options – ● If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6. ● If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.5. |

| Symptom 2 | DIAGNOSTIC PROCEDURE |
|--|--|
| (continued) | |
| Drive does not start. Amber POWER ON LED is illuminated. No red fault LEDs are illuminated. | <p>STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T.</p> <p>The following voltages should be present at Power Supply Board A6.</p> <p>molex connector J602 between pins 4 & 1 14V AC molex connector J602 between pins 2 & 1 14V AC molex connector J602 between pins 5 & 6 15V AC</p> <p>The following voltage should be present at terminal block 1TB.</p> <p>between terminals 1 & 11 90V AC</p> <p>If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.</p> <p>STEP 7 – Go to Logic Power Supply Board A6 and measure all output voltages. The following voltages should be present at molex connector J601 with respect to Drive common, J601 Pin 1. If any one voltage is absent, replace A6.</p> <p>J601, pin 2 14V AC J601, pin 3 +17V DC J601, pin 5 +9 to +15V DC (nominal) J601, pin 6 +9 to +15V DC (nominal) J601, pin 9 -17V DC</p> <p>STEP 8 – Measure the output voltage across the secondary circuit of Transformer 2T, pins 5 & 6. If 31V AC is absent, replace 2T.</p> <p>STEP 9 – If 2T checks out, Contactor Interface Board A9 may be inoperative. First check input protection fuse 9FU for an open condition, then the Contactor Interface Board. The following voltages should be present with respect to Drive common, J901 Pin 1.</p> <p>J901, pin 4 +24V DC J901, pin 6 0V DC (nominal) J901, pin 7 0V DC (nominal) J901, pin 8 +11V DC</p> <p>STEP 10 – If Transformer 2T and Contactor Interface Board A9 check out, measure the control voltage at contactor 1CON. There should be +24V DC between points C1 & C2 at the contactor. If +24V DC is measured and 1CON is not picked-up, the contactor may be inoperative. Replace if required.</p> <p>If the problem cannot be found after completing STEPS 1 – 10, replace Modulator Logic Board A1.</p> |

| Symptom 3 | DIAGNOSTIC PROCEDURE | | | | | | |
|--|--|---|--------------------------------------|---------------------------------------|--|--|--|
| Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated. | <p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse 5FU for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assemblies and Bus Capacitors as specified in STEPS 1, 2 & 3, Symptom 1.</p> <p>STEP 2 – Check Precharge Contactor Interface Board A9. The following voltages should be present at connector J901 on the Contactor Interface Board. Replace if required.</p> <table> <tr> <td>Transformer 2T secondary voltage</td><td>17V AC between pins 2 & 3</td></tr> <tr> <td>Contactor 1CON control voltage</td><td>+ 24V DC between pins 4 & 6</td></tr> <tr> <td></td><td>+ 11V DC between pins 7 & 8</td></tr> </table> <p>If the problem cannot be found after completing STEPS 1 & 2, replace Modulator Logic Board A1.</p> | Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | + 11V DC between pins 7 & 8 |
| Transformer 2T secondary voltage | 17V AC between pins 2 & 3 | | | | | | |
| Contactor 1CON control voltage | + 24V DC between pins 4 & 6 | | | | | | |
| | + 11V DC between pins 7 & 8 | | | | | | |

| Symptom 4 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive trips just after input line power is applied before START command is given. Current limiting circuit not functioning properly. Red OVERLOAD fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>STEP 1 – Check the power supply at all three Driver Boards. Approximately 16V AC should be measured between pins 1 & 2 at each J301 connector. If not, check fuse F1 on Driver Power Supply Board A10. Replace if required and check voltage again.</p> <p>If voltage is not present, replace Driver Power Supply Board A10.</p> <p>If voltage is present, complete STEP 2.</p> <p>STEP 2 – Remove input power to the Drive and check connections between J4201 on the LEM Board and pins 7 & 8 at connector J303 on each Driver Board. Check connections between E6, E10 & E14 on the LEM Board and E1 on Power Switching Module 1Q1, 2Q1 & 3Q1 respectively. If the problem still cannot be located, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> |

| Symptom 5 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive trips off during normal operation. Red OVERLOAD and PROT. A fault LEDs are illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>When both the OVERLOAD and PROT. A LEDs are illuminated, there may be a loss of input power to the LEM Board.</p> <p>Check fuse 7FU on fan transformer 3T for an open condition. Check connections between terminals 5 & 6 on transformer 3T and push-on connectors E1 & E2 on the LEM Board. 115V AC should be measured. If the problem still cannot be located, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> |

| Symptom 6 | DIAGNOSTIC PROCEDURE |
|---|--|
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red OVERLOAD fault LED is illuminated. | <div> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated OVERLOAD LED indicates that the Drive has tripped off due to a nominal 110% overload condition which has exceeded the (60) second time period.</p> <div> <p>IMPORTANT : <i>During acceleration or startup (breakaway), it is normal for the Overload LED to illuminate momentarily. This merely indicates that a momentary overload current of 110% has been sensed and that the Overload circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the Overload LED is constantly activated during startup (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p> |

| Symptom 7 | DIAGNOSTIC PROCEDURE |
|--|---|
| Motor does not return to full set speed after stalling. Red OVERLOAD fault LED is illuminated. | <p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.</p> <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT: <i>If a continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the Overload LED on the Diagnostic Display Panel.</i></p> </div> |
| Symptom 8 | DIAGNOSTIC PROCEDURE |
| Red OVERLOAD fault LED is illuminated during DECEL or at (0) Hz. | <p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p> |
| Symptom 9 | DIAGNOSTIC PROCEDURE |
| Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated. | <div style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than 414V AC at the 460V AC Tap on Transformer 1T</p> <ul style="list-style-type: none"> ● 414V AC at the 460V AC Tap on Transformer 1T ● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power) ● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse 4FU and Contactor Interface Board protection fuse 9FU for an open condition.</p> <p>STEP 2 – Measure the input voltage to Transformer 1T. If proper voltage is present, replace Modulator Logic Board A1.</p> |

| Symptom 10 | DIAGNOSTIC PROCEDURE |
|---|---|
| Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated. | <p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none">● Excessively High Input Voltage● DC Boost Set too High● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office.</p> |

Symptom 11

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **A**, **B** or **C** phase protection LED indicates:

- **An output overcurrent condition greater than 180% due to either:**

- 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor).
- 2) An output overcurrent condition greater than 180% due to an output phase-to-ground short.

In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block 2TB. Reapply power to the Drive and give the Drive a **START** command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.

A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.

A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.

- **Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate.**

Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied, the motor can saturate, resulting in a peak current in excess of 180% causing a phase protect trip. Decrease the **DC BOOST**, the **DECEL RATE** or both. Refer to section 5.3.3, **DC Boost Adjustment, ACCEL/DECEL Rate Adjustment** for additional information.

- **Excessive DC boost causing a phase protection trip during acceleration.**

Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.

If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center, Drives Distributor, or Sales Office for application assistance.

Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.

| Symptom 11 | DIAGNOSTIC PROCEDURE |
|---|---|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <ul style="list-style-type: none"> ● A shorted output transistor in one of the Power Switching Modules. Phase "A" ... 1Q1, 1Q2 Phase "B" ... 2Q1, 2Q2 Phase "C" ... 3Q1, 3Q2 Perform the following four steps to isolate and correct the problem. ● A malfunctioning Driver Board. Phase "A" ... A3A Phase "B" ... A3B Phase "C" ... A3C Perform the following four steps to isolate and correct the problem. ● A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be. Phase "A" ... A3A Phase "B" ... A3B Phase "C" ... A3C Perform the following four steps to isolate and correct the problem. ● A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform. Perform the following four steps to isolate and correct the problem. <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. DS1, the bus charged neon light on Bus Indicator Board A41 should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage at connector J402 between pins 5 (+BUS) and 1 (– BUS) on Voltage Sensing Board A4. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> |


Symptom 11

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

Connections Listed in Step 2 are shown in detail on page D-4



STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Disconnect all leads to **C1** at the Power Switching Module.

Disconnect all leads to **E2** at the Power Switching Module.

Unplug the molex connector for the indicated phase at the Driver Board (**J303A**, **B**, or **C**).

Disconnect one end of the jumper bar that is connected between terminals **E1**, **C2** on the two power switching modules. This will enable you to check each transistor independently.

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of each module as follows.

| <u>OHMMETER</u> | | <u>READING</u> |
|-----------------|---------------|-----------------|
| <u>+ LEAD</u> | <u>– LEAD</u> | |
| C1 | E1 | INFINITE |
| C2 | E2 | INFINITE |

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of each module as follows.

| <u>OHMMETER</u> | | <u>READING</u> |
|-----------------|---------------|-----------------|
| <u>+ LEAD</u> | <u>– LEAD</u> | |
| C1 | B1 | INFINITE |
| C2 | B2 | INFINITE |

If a short is found, replace the module and check the following.

IMPORTANT : When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

- DC Bus Fuse **8FU** for an open condition.
- Fuse **F1** on Driver Power Supply Board **A10**. If fuse **F1** is open, replace the board.
- Fuses **F1** & **F2** on the Driver Board for the indicated phase. If either fuse is open or it was noted that with input power applied either LED on the Driver Board was illuminated, replace the Driver Board. An illuminated LED indicates an open fuse which usually indicates failed components on the Driver Board.

| Symptom 11 | DIAGNOSTIC PROCEDURE |
|---|--|
| <p>(continued)</p> <p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red PROT. A, PROT. B, or PROT. C fault LED is illuminated.</p> | <p>STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to MANUAL control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed, check operation in the auto or normal operating mode. If Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, perform STEP 5 below.</p> <p>(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)</p> <p>STEP 5 – Check for proper operation of the current sensing circuits on the Modulator Logic Board and the Driver Board for the indicated phase.</p> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The OVERLOAD LED on the Modulator Logic Board should light when the current reaches a nominal value of 110%. If the OVERLOAD LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <p style="text-align: center;">Pin 5 – ØA Driver Signal Pin 16 – ØB Driver Signal Pin 27 – ØC Driver Signal</p> <p>If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.</p> <p>If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p> |

Symptom 12

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **DRIVE OVER TEMP** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **DRIVE OVER TEMPERATURE** LED indicates that the Drive has tripped off due to an over temperature condition. Allow the Drive to cool down for approximately (15) minutes before restarting. After restarting, if an over temperature condition occurs again, check for the following conditions.

- **Ambient Temperature that Exceeds the Drive Rating.** Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3.
- **Heat Flow Obstruction within the Heat Sink Assembly.** Visually inspect for unobstructed spacing between fins. Clean if necessary.
- **Drive Fan Obstruction, Open Fan Fuse 7FU or Malfunctioning Fan.** Check and replace as required.
- **Open Winding or Connection to Transformer 3T.** Check for 115V AC between terminals 5 & 6 on transformer 3T. Replace if required.
- **Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time.** Using an AC clamp on ammeter, measure the motor current over an extended period of time.

IMPORTANT : *Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.*

- **Malfunctioning Temperature Sensor 1TAS.** If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS.

IMPORTANT : *When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.*

Symptom 13

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **OUTPUT GND** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **OUTPUT GROUND** LED indicates that the Drive circuitry has shorted to ground or there is a malfunctioning Output Ground Sensor Board A8.

Remove input power to the Drive and disconnect the motor from the Drive. Reapply input power and start the Drive.

If the Drive does not trip, check the motor for a grounded phase condition. Replace or repair the motor if required.

If the Drive trips with the motor disconnected, check wire insulation and terminal connections on the Drive Chassis for shorts to ground. If the problem still cannot be located, replace Output Ground Sensor Board A8.

Symptom 14

DIAGNOSTIC PROCEDURE

Bus voltage does not discharge within (60) seconds when input power is removed. Neon light **DS1** on Bus Indicator Board A41 is illuminated. Red **OVERLOAD LED** may or may not be illuminated.

After input power is removed the bus voltage should discharge to 42V DC in approximately (60) seconds if the discharge cycle is taking place.


STEP 1 – If the **OVERLOAD LED** is illuminated, check the power supply at all three Driver Boards. Approximately 16V AC should be measured between pins **1** & **2** at each **J301** connector. If not, check fuse F1 on Driver Power Supply Board A10. Replace if required and check voltage again. If voltage is still not present, replace Driver Power Supply Board A10.


STEP 2 – If the **OVERLOAD LED** is not illuminated, check to see if resistor 2R or 3R has opened.
If neither resistor is open, check for open wiring between the resistors and Bus Capacitors 2C & 3C.
If either resistor is open, replace and reapply input power.

IMPORTANT : *When replacing resistor 2R or 3R, clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the resistor. Torque mounting screws to 2.6-3.0 in-lbs max.*


Check for proper bus discharge cycle by measuring the DC Bus voltage at Voltage Sensing Board A5, connector **J402**, between pins **5** (+ BUS) and **1** (– BUS). After approximately (60) seconds the voltage should be below 42V DC. If discharge cycle is still not taking place and/or either resistor opens again, replace Voltage Sensing Board A41.

Bulletin 1335 12 & 16 Amp Drive Schematics






12 & 16 Amp Power Distribution Board Schematic






- ① REFER TO BULLETIN 1335 12 & 16 AMP UNIT SCHEMATIC
 - ② DO NOT USE THE 90V AC OPTION SUPPLY FOR ANYTHING OTHER THAN THE CONTROL SCHEMES SHOWN IN SECTION 4.4
 - ③ REMOVE JUMPER WHEN CONNECTING OPTION
 - ④ JUMPER REMOVED AND SHUNT INSTALLED WHEN OUTPUT DIGITAL AMMETER IS CONNECTED
 - ⑤ REFER TO APPENDIX A FOR FUSE VALUE
-




Bulletin 1335 22, 28 & 36 Amp Unit Schematics



22 & 28 Amp Unit Schematic







36 Amp Unit Schematic







Bulletin 1335 56 & 69 Amp Unit Schematic






Bulletin 1335 77 & 96 Amp Unit Schematic






Bulletin 1335 Modulator Logic Board Interconnection Diagrams


12 & 16 Amp Modulator Logic Board Interconnection Diagram







SET-POINT FREQUENCY CONTACT CARD
OPTION W2






BCD INTERFACE CARD
OPTION G4
— OR —
ISOLATED SIGNAL CONDITIONER CARD
OPTION N
— OR —
ISOLATED SIGNAL CONDITIONER CARD
OPTION N4



MODULATOR LOGIC BOARD A1




RIBBON CABLE
TO J301
DRIVER BOARD A3




22-96 Amp Modulator Logic Board Interconnection Diagram

① DO NOT USE THE 90V AC OPTION SUPPLY FOR ANYTHING OTHER THAN THE CONTROL SCHEMES SHOWN IN SECTION 4.4



SET-POINT FREQUENCY CONTACT CARD
OPTION W2



BCD INTERFACE CARD

OPTION G4

— OR —


ISOLATED SIGNAL CONDITIONER CARD

OPTION N






— OR —

ISOLATED SIGNAL CONDITIONER CARD

OPTION N4



MODULATOR LOGIC BOARD A1




RIBBON CABLE TO OUTPUT DIGITAL AMMETER
OPTION A, A2

RIBBON CABLE TO OUTPUT DIGITAL VOLTMETER CARD
OPTION B, B2

RIBBON CABLE TO PROGRAMMABLE SPEED METER CARD
OPTION E


Bulletin 1335 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J104




Bulletin 1335 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J102



- OR -



Bulletin 1335 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J104



**FUNCTION EXPANDER CARD
OPTION L**

– OR –




EUROCARD

Bulletin 1335 Modulator Logic Board Plug-In Options


CARD EDGE CONNECTOR J105

**SET-POINT FREQUENCY CONTACT CARD
OPTION W2
— REV 4 OR LATER —**




— OR —

**SET-POINT FREQUENCY CONTACT CARD
OPTION W2
— REV 3 OR EARLIER —**




Bulletin 1335 Modulator Logic Board Plug-In Options


CARD EDGE CONNECTOR J103



- OR -



- OR -





THE ALLEN-BRADLEY COMMITMENT TO TOTAL QUALITY . . .

DRIVES TRAINING





Congratulations on your recent purchase of an Allen-Bradley AC Industrial, DC Industrial or Motion Control Drive. We offer a wide range of training programs to satisfy the needs of those who apply, start-up and maintain drives. Training programs tailored to your needs range from general industrial drive programs to specific product training courses. Courses are taught at local Area Support Centers, our Wisconsin Headquarters Training Center, or adapted for on-site training at your plant.

We offer customer training programs in the following product areas:

- AC Industrial Drives
- DC Industrial Drives Schools
- Motion Control Drives
- DC Customer Maintenance Schools

We offer traditional training programs in the following categories:

- On-Site Training
- Regional Service Center Schools
- Customized Factory Schools
- Modular Training Programs
- Audio/Visual Training Aids
- Computer Based Instruction



At Allen-Bradley . . . We provide Winning Answers

Write to us for further information on how we can best meet your training needs.

(Please Print)

Name _____

Title _____

Company _____

Address _____

City _____ State _____ Zip _____

Telephone () _____ - _____

- ☐ AC Industrial Drives
- ☐ DC Industrial Drives
- ☐ Motion Control Drives
- ☐ Drive Systems
- ☐ Regional Service Center Schools
- ☐ On-Site Training
- ☐ Customized Factory Schools
- ☐ Modular Training Programs
- ☐ Audio/Visual Training Aids
- ☐ Computer Based Instruction

SEAL WITH TAPE ONLY

FOLD HERE

FOLD HERE



BUSINESS REPLY MAIL


FIRST CLASS MAIL PERMIT NO. 1594 MILWAUKEE, WI

POSTAGE WILL BE PAID BY ADDRESSEE

ALLEN-BRADLEY

Attn: Training Department
Motion Control Division
P.O. Box 760
Mequon, WI 53092-0760

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES





How Can We Improve ?

We would appreciate your comments on the usefulness and readability of this manual. *Please* take a few moments to complete the following questions. If desired, provide specific examples that would make this manual a more useful tool.

PUBLICATION NAME _____

PUBLICATION NUMBER AND DATE _____

PLEASE RATE THE FOLLOWING ITEMS

| | | | |
|---|-----------------------------------|-------------------------------------|-------------------------------------|
| COMPARED TO SIMILAR MANUALS, THIS MANUAL IS ... | <input type="checkbox"/> BETTER | <input type="checkbox"/> AS GOOD | <input type="checkbox"/> POOR |
| ORGANIZATION OF MATERIAL IS ... | <input type="checkbox"/> GOOD | <input type="checkbox"/> ADEQUATE | <input type="checkbox"/> POOR |
| EASE OF READING IS ... | <input type="checkbox"/> GOOD | <input type="checkbox"/> ADEQUATE | <input type="checkbox"/> POOR |
| LEVEL OF INFORMATION IS ... | <input type="checkbox"/> GOOD | <input type="checkbox"/> ADEQUATE | <input type="checkbox"/> POOR |
| PHOTOGRAPHS AND/OR ILLUSTRATIONS ARE ... | <input type="checkbox"/> GOOD | <input type="checkbox"/> ADEQUATE | <input type="checkbox"/> POOR |
| THE AMOUNT OF INFORMATION WAS ... | <input type="checkbox"/> TOO MUCH | <input type="checkbox"/> TOO LITTLE | <input type="checkbox"/> JUST RIGHT |
| THE METHOD OF PAGE BINDING IS ... | <input type="checkbox"/> GOOD | <input type="checkbox"/> ADEQUATE | <input type="checkbox"/> POOR |

DID YOU FIND ANY ERRORS ?

PAGE _____ ERROR _____

PAGE _____ ERROR _____

PAGE _____ ERROR _____

WERE THERE ANY AREAS THAT WERE NOT CLEAR OR HARD FOR YOU TO UNDERSTAND ?

PAGE _____ DESCRIBE _____

PAGE _____ DESCRIBE _____

PAGE _____ DESCRIBE _____

COMMENTS ?

YOUR POSITION ... ☐ MAINTENANCE ☐ ENGINEER ☐ MANAGERIAL ☐ OTHER _____

EXPERIENCE WITH MOTION CONTROLS ... ☐ VERY EXPERIENCED ☐ SOMEWHAT EXPERIENCED ☐ LIMITED EXPERIENCE

COMPLETE THE FOLLOWING, IF DESIRED

YOUR NAME _____ TITLE _____

COMPANY NAME _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

THANK YOU FOR HELPING US TO SERVE YOU BETTER !!

SEAL WITH TAPE ONLY

FOLD HERE

FOLD HERE



BUSINESS REPLY MAIL

FIRST CLASS MAIL PERMIT NO. 1594 MILWAUKEE, WI

POSTAGE WILL BE PAID BY ADDRESSEE

ALLEN-BRADLEY

Attn: Marketing Communications
Motion Control Division
P.O. Box 760
Mequon, WI 53092-0760

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



Notes

Notes



ALLEN-BRADLEY
A ROCKWELL INTERNATIONAL COMPANY

A subsidiary of Rockwell International, one of the world's largest technology companies, Allen-Bradley meets today's automation challenges with over 85 years of practical plant floor experience. More than 12,000 employees throughout the world design, manufacture and apply a wide range of control and automation products and supporting services to help our customers continuously improve quality, productivity and time to market. These products and services not only control individual machines, but also integrate the manufacturing process while providing access to vital plant floor data that can be used to support decision-making throughout the enterprise.

With offices in major cities worldwide.

WORLD HEADQUARTERS

Allen-Bradley
1201 South Second Street
Milwaukee, WI 53204 USA
Tel: (1) 414 382-2000
Telex: 43 11 016
Fax: (1) 414 382-4444

**EUROPE/MIDDLE EAST/
AFRICA HEADQUARTERS**

Allen-Bradley Europe B.V.
Amsterdamseweg 15
1422 AC Uithoorn
The Netherlands
Tel: (31) 2975/43500
Telex: (844) 18042
Fax: (31) 2975/60222

ASIA/PACIFIC HEADQUARTERS

Allen-Bradley (Hong Kong) Limited
Room 1006, Block B, Sea View Estate
2-8 Watson Road
Hong Kong
Tel: (852) 887-4788
Telex: (780) 64347
Fax: (852) 510-9436

CANADA HEADQUARTERS

Allen-Bradley Canada Limited
135 Dundas Street
Cambridge, Ontario N1R 5X1
Canada
Tel: (1) 519 623-1810
Fax: (1) 519 623-8930

**LATIN AMERICA
HEADQUARTERS**

Allen-Bradley
1201 South Second Street
Milwaukee, WI 53204 USA
Tel: (1) 414 382-2000
Telex: 43 11 016
Fax: (1) 414 382-2400